

# EL-O-Matic F-Series

## Rack and Pinion Pneumatic Actuators





# Table of Contents

<b>Section 1: Before You Start</b>	
1.1	Installation, Operation and Maintenance Reference Documents ..... 1
1.2	Warehouse Storage ..... 1
1.3	On-Site Storage ..... 2
<b>Section 2: Introduction</b>	
2.1	Identification ..... 3
2.2	Intended Use ..... 4
2.3	Specifications ..... 4
<b>Section 3: Product Code</b>	
3.1	Configuration code for a default actuator..... 6
<b>Section 4: Installation</b>	
4.1	Before You Start..... 7
4.2	Failure Modes ..... 7
4.2.1	Valve Rotation ..... 7
4.2.2	Position After Failure..... 8
4.3	Principles of Operation..... 8
4.3.1	Solenoid Valve ..... 8
4.3.2	Ingress Protection (IP) rating ..... 9
4.3.3	Double-Acting Actuators ..... 10
4.3.4	Spring-Return Actuators ..... 11
4.4	Actuator Assembly Codes ..... 12
4.5	Actuator to Valve Installation ..... 13
4.6	Mounting of control and feedback accessories..... 15
4.7	Recommended Tubing Sizes ..... 16
<b>Section 5: Mechanical Stroke Adjustment</b>	
5.1	Travel Stop Adjustment ..... 18
5.1.1	Double-Acting Actuators ..... 18
5.1.2	Spring-Return Actuators ..... 18
5.1.3	Angular Displacement ..... 19
<b>Section 6: Maintenance</b>	
6.1	General..... 20
6.2	Repair ..... 20
6.2.1	Spring-Return actuator ..... 20
6.2.2	Recommended Spare Parts..... 20

---

<b>Section 7:</b>	<b>Decommission (Out of Service)</b>	
7.1	Before You Start .....	21
7.2	Removing the actuator from the valve .....	22
<b>Section 8:</b>	<b>Disassembly</b>	
8.1	Removing End Caps .....	24
8.2	Removing Spring Cartridges (Spring-Return) .....	25
8.3	Removing of Limit Stop .....	26
8.4	Removing Pistons .....	26
8.5	Removing Pinion.....	27
8.6	Cleaning the Body.....	27
<b>Section 9:</b>	<b>Reassembly</b>	
9.1	Grease Instructions.....	29
9.2	Reassembly of the pinion .....	30
9.3	Reassembly of the pistons.....	31
9.4	Reassembly and settings of the limit stops .....	33
9.5	Reassembly of the end caps .....	33
	9.5.1 Double-Acting actuators .....	33
	9.5.2 Spring-Return actuators .....	35
9.6	Basic function and Air Leak Test .....	37
<b>Section 10:</b>	<b>Troubleshooting</b>	
10.1	Mechanical Problems.....	38
10.2	Pneumatic Problems.....	39
10.3	Electrical Problems .....	40
<b>Section 11:</b>	<b>Parts List and Spare Parts Recommendations</b>	
11.1	Exploded View and Parts List.....	41
<b>Appendix A:</b>	<b>Spring load removal</b>	
A.1	Spring load relief .....	42
<b>Appendix B:</b>	<b>Tool &amp; Torque Table</b>	
»	Table B-1 End cap bolts .....	44
»	Table B-2 Bottom Flange .....	44
»	Table B-3 NAMUR (VDE/VDI 3845) flanges .....	45
»	Table B-4 Limit stop dimensions .....	45
»	Table B-5 Recommended circlip pliers.....	45

# Section 1: Before You Start

This section explains:

- Base safety procedures
- Where to find detailed information relating safety.
- Storage guidelines.

Installation, adjustment, putting into service, use, assembly, disassembly and maintenance of the pneumatic actuator must be performed by qualified personnel.

## **⚠ NOTICE**

Failure to follow the above guidelines will void warranty.

## **⚠ WARNING**

Actuator must be isolated both pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembly, the actuator consult the relevant sections of this manual.

## 1.1 Installation, Operation and Maintenance Reference Documents

Before you start, read the following documents:

- All chapters in this manual.
- Safety Guide (Document No. DOC.SG.EF.EN).

## **⚠ NOTICE**

Failure to read the Safety Guide will void the warranty.

Not following the instructions of the Safety Guide can lead to failure of the product and harm to personnel or equipment.

## 1.2 Warehouse Storage

- All actuators should be stored in a clean, dry warehouse, free from excessive vibration and rapid temperature changes.
- All actuators should not be stored directly to the floor surface - it must be placed in racks/shelves or use a pallet.

## 1.3 On-Site Storage

- All actuators should be stored in a clean, dry warehouse, free from excessive vibration and rapid temperature changes.
- Prevent moisture or dirt from entering the actuator. Plug or seal both air connection ports.

### **NOTICE**

Failure to follow the above guidelines (Warehouse and On Site Storages) will void warranty.

---

## Section 2: Introduction

This section explains:

- How to identify the received product,
- The intended use of the product
- Construction details
- Actuator specifications

### 2.1 Identification


The EL-O-Matic F Rack and Pinion actuators are available as double-acting or spring-return versions. 13 models are available, ranging from 12 Nm to 4000 Nm (106 to 35000 lbf.in) nominal torque output.

The EL-O-Matic F-Series uses standardized interfaces for solenoid, switchbox or positioner mounting (VDI/VDE3845; NAMUR). The valve interface is equipped with an insert in the pinion bottom that allows both ISO5211 or DIN3337 mounting.

The springs in the spring-return version allow a fail action in case of loss of air supply pressure (Fail-to-Close or Fail-to-Open).

As from size FD150 double-acting versions have flat end caps to reduce actuator length and internal air volume.

**Figure 1 Identification**



1. Top auxiliaries interface (VDI/VDE 3845; NAMUR)
2. Solenoid interface (VDI/VDE 3845; NAMUR)
3. Valve interface with ISO5211, DIN 3337 patterns and insert drive
4. Spring-return actuators: - with springs
5. Double-acting actuators: - no springs
6. High end caps for double-acting and spring-return models up to size 100
7. Low end caps for double-acting models as from size 150 and larger

## 2.2 Intended Use

The EL-O-Matic F Rack and Pinion actuators are intended for the automation and operation of quarter-turn valves like Butterfly, Ball and Plug valves.

Rack and Pinion actuators can also be used to operate dampers or any other quarter-turn applications.

## 2.3 Specifications

**Table 1. Pressure Range**

Actuator Type	Pressure
Double-Acting	0.2 to 8.3 barg (2.9 to 120 psig)
Spring-Return	6 to 8.3 barg (87 to 120 psig), with maximum spring set
	3 to 8.3 barg (43.5 to 120 psig), reduced spring quantity

**Table 2. Operating Media**

Actuator Type	Operating Media
Double-Acting and Single-Acting	Air, dry or lubricated and inert gases
	Dew point at least 10K below ambient temperature
	For sub-zero applications, take appropriate measures
	Mentioned pressure levels are "gauge pressures". Gauge pressure is equal to absolute pressure minus atmospheric pressure.

**Table 3. Temperature Range**

Actuator Type	Temperature
Standard	-20°C to +80°C (-4°F to +176°F)
Option: Low Temperature	-40°C to +80°C (-40°F to +176°F)
Option: High Temperature	-20°C to +120°C (-4°F to +248°F)

**Table 4. Air Volumes and Consumption**

Actuator volumes:			
Actuator size	Maximum volume (in liters)		
	Central <sup>1</sup> chamber	End cap <sup>2</sup> chamber	Displaced <sup>3</sup> volume
12	0.05	0.06	0.04
25	0.11	0.19	0.08
40	0.16	0.36	0.15
65	0.36	0.55	0.22
100	0.4	0.8	0.3
150	0.8	0.7	0.5
200	0.8	1.0	0.7
350	1.9	1.7	1.2
600	3.1	2.9	2.1
950	5.1	4.3	3.2
1600	7.8	7.0	5.2
2500	10.4	11.1	8.2
4000	18.4	18.9	14.0


Consumption per stroke (in liters, pressure in barg)					
Outward Stroke			Inward Stroke		
Double-Acting and Spring-Return			Double-Acting only		
2	4	8	2	4	8
0.14	0.24	0.4	0.16	0.28	0.5
0.29	0.50	0.9	0.46	0.85	1.6
0.47	0.8	1.5	0.87	1.6	3.0
0.9	1.6	3.1	1.3	2.4	4.6
1.0	1.7	3.2	2.0	3.6	6.9
2.1	3.6	6.8	1.9	3.4	6.2
2.4	4.0	7.3	2.7	4.6	8
5.1	9	17	5	8	15
8	14	27	8	14	25
13	23	44	12	20	37
21	36	68	19	33	62
29	50	92	30	53	97
51	87	161	52	89	165

Actuator volumes:			
Actuator size	Maximum volume (Cu.in.)		
	Central <sup>1</sup> chamber	End cap <sup>2</sup> chamber	Displaced <sup>3</sup> volume
12	3.1	3.7	2.5
25	6.4	11.8	4.7
40	10.0	22	8.9
65	22	34	13.5
100	22	50	19.9
150	48	43	32
200	50	59	44
350	118	103	76
600	189	174	129
950	310	260	193
1600	477	430	319
2500	638	676	501
4000	1122	1151	853

Consumption per stroke (in Cu.in., pressure in psig)					
Outward Stroke			Inward Stroke		
Double-Acting and Spring-Return			Double-Acting only		
2	4	8	2	4	8
11	19	28	13	23	33
23	40	58	37	70	102
36	64	92	70	131	192
74	134	194	107	200	293
80	140	200	158	295	433
163	295	427	151	270	389
182	320	458	207	369	532
402	729	1055	359	642	925
650	1171	1692	610	1091	1571
1049	1905	2760	910	1628	2346
1635	2951	4267	1505	2691	3877
2259	4018	5776	2367	4232	6097
3946	7040	10134	4027	7202	10377

1. For Double-Acting and Spring-Return. Pistons at 90° outward position
2. Only for Double-Acting. Pistons at 0° inward position
3. Stroke is 90°


**Figure 2 Actuator air volumes**



## Section 3: Product Code

This section explains:

- How to create the configuration code for a default actuator.
- How to create the configuration code for an actuator with added integral options.



Type:	
FD	Double-Acting
FS	Spring-Return

Size:
Body sizes: 0012, 0025, 0040, 0065, 0100, 0150, 0200, 0350, 0600, 0950, 1600, 2500 and 4000

Threads:	
M	Metric - ISO 5211
U	Imperial - ISO 5211 (UNC/NPT)

Spring set:	
00	For Double-Acting (no springs)
10, 20, 30, 40, 50 or 60	For Spring-Return

Rotation:	
CW	Spring to Close / Clockwise
CC	Spring to Open / Counterclockwise

Pinion material:	
AL	Aluminium, hard anodized

Valve Interface:	
T	Standard ISO 5211 - interface
S	Small interface with center plate DIN 3337
L	Large interface with center plate DIN 3337

Valve Stem connection (Insert Sizes):	
0000	No Insert

Parallel drive: □	Diagonal drive : ◇	Square:	Actuator size(s):
NL11	YD11	11 mm / 0.433"	0025
NL14	YD14	14 mm / 0.551"	0040 & 0065
NL19	YD17	17 mm / 0.669" 19 mm / 0.748"	0100 & 0150
NL22	YD22	22 mm / 0.866"	0200
NL27	YD22	22 mm / 0.866" 27 mm / 1.063"	0350
NL27	YD27	27 mm / 1.063"	0600
NL36	YD36	36 mm / 1.417"	0950
NL46	YD46	46 mm / 1.811"	1600 & 2500
NL55	YD55	55 mm / 2.165"	4000

1. See data sheet EFG.05.01.EN for a more detailed overview of available inserts.
2. Drive insert designation is according to ISO 5211.

Temperature Ranges:		
S	Standard:	-20°C to +80°C (-4°F to -176°F)
H	High Temperature:	-20°C to +120°C (-4°F to +248°F)
L	Low Temperature	-40°C to +80°C (-40°F to +176°F)

Visual indicator:	
K	Standard (knob style)
N	No Visual indicator

Finish:	
A	Standard coating
C	CSR coating

Note: CSR coating not available for Size 2500 and 4000

Internal code 1:	
00	Standard

Internal code 2:	
XX	Standard

## Section 4: Installation

This section explains:

- The "Failure Modes" of an actuator.
- In which position the actuator will end after a failure.
- Principles of operation:
  - Solenoid operation
  - Double acting and Spring return operation
- Assembly codes.
- Actuator to valve assembly.

### 4.1 Before You Start

#### **⚠ SAFETY FIRST**


In case of an air or electrical failure, it is important to know the behavior of the actuator. Before mounting the actuator on a valve, consult the following sections below.

### 4.2 Failure Modes

#### 4.2.1 Valve Rotation

For the following paragraphs we assume that valves rotate as indicated in figure 3.

Figure 3 Normal valve rotation



## 4.2.2 Position After Failure

The position of the actuator after a failure depends on the:

1. Principle of operation (see paragraph 4.3)
2. Assembly codes (see paragraph 4.4)
3. Kind of failure. Refer to the table below.

**Table 5. Position After Failure**


Principle of Operation	Assembly Code	Kind of Failure	Position
Double-Acting Actuator		Pressure	Not defined
		Signal	Closed
		Supply Voltage	Closed
		Pressure	Not defined
		Signal	Open
		Supply Voltage	Open
Single-Acting (Spring-Return) Actuator		Pressure	Closed
		Signal	Closed
		Supply Voltage	Closed
		Pressure	Open
		Signal	Open
		Supply Voltage	Open

## 4.3 Principles of Operation

### 4.3.1 Solenoid Valve

All actuators can be either piped with solid or flexible tubing with the solenoid valve mounted remotely from the actuator or by mounting a VDI/VDE 3845 (NAMUR) designed solenoid valve DIRECTLY onto the NAMUR mounting pad on the side of the actuator

**Figure 4 Typical solenoid operation**



The table below represents the cycle time (operating time) per different Actuator sizes:

**Table 6. Operating Speed**

Cycle time in seconds				
Actuator size	Spring-Return		Double-Acting	
	A-port pressurized	Spring stroke	A-port pressurized	B-port pressurized
F 12	0.4	0.4	0.4	0.4
F 25	0.5	0.4	0.5	0.4
F 40	0.6	0.5	0.6	0.5
F 65	0.7	0.5	0.6	0.6
F 100	0.8	0.6	0.8	0.7
F 150	1.0	0.8	0.9	0.8
F 200	1.3	0.9	1.0	1.0
F 350	1.9	1.3	1.4	1.5
F 600	3.2	1.9	2.2	2.2
F 950	4.6	3.2	3.9	3.6
F 1600	6.9	4.8	5.9	4.8
F 2500	9.0	6.3	7.8	7.9
F 4000	15.4	10.8	13.3	13.0

Operating time is average with actuator under load and solenoid valve fitted.

Test conditions:

- |                                 |                        |
|---------------------------------|------------------------|
| 1. Solenoid with flow capacity: | 0.6 m <sup>3</sup> /hr |
| 2. Pipe diameter:               | 6mm                    |
| 3. Medium:                      | clean air              |
| 4. Supply pressure:             | 5.5 bar (80psi)        |
| 5. Load:                        | with average load      |
| 6. Stroke:                      | 90°                    |
| 7. Temperature:                 | Room temperature       |

### 4.3.2 Ingress Protection (IP) rating

EL-O-Matic F actuators are IP66/IP67 rated. In case of IP66 or IP67 requirements, take precautions that comply with the IP66/IP67 requirements to prevent moisture or dust from entering the actuator through the open air exhaust port(s), either directly on the actuator or at the exhaust ports of the connected solenoid valve.

We recommend to connect tubing to the exhaust(s) and lead this into a dry and dust free area, or to use check valves in the exhaust.


### 4.3.3 Double-Acting Actuators

The operating principle, as explained here, is applicable for actuators with assembly code CW (direct acting).


- Applying supply pressure to port A will move the pistons outward to the "Open" position of the valve.
- Applying supply pressure to port B will move the pistons inward to the "Close" position of the valve.
- For assembly codes CC, the operating principle is reversed (reverse acting).

**Figure 5 Double-Acting Operation**

#### Outward Stroke



#### Inward Stroke




### 4.3.4 Spring-Return Actuators

The operating principle, as explained here, is applicable for actuators with assembly code CW (direct acting).


- Applying supply pressure to port A will move the pistons outwards to the "Open" position of the valve.
- Venting the supply pressure from port A will cause the springs to move the pistons inwards to the "Close" position of the valve.
- For assembly codes CC, the operating principle is reversed (reverse acting).

**Figure 6 Stroke Movements**

#### Outward Stroke



#### Inward Stroke




## 4.4 Actuator Assembly Codes

Figure 7 Assembly Code - Double-Acting


**Assembly code: CW**

- = Standard, Clockwise-to-Close rotation
- = Fail-to-Close



**Assembly code: CC**

- = Reverse, Counterclockwise-to-Open
- = Fail-to-Open



A = Rotation when central air chamber is pressurized.


B = Rotation when end cap air chambers are pressurized.

All views are from above. Pistons are shown in inward position.

Figure 8 Assembly Code - Spring-Return


**Assembly code: CW**

- = Standard, Clockwise-to-Close rotation
- = Fail-to-Close



**Assembly code: CC**

- = Reverse, Counterclockwise-to-Open
- = Fail-to-Open



## 4.5 Actuator to Valve Installation

### ⚠ WARNING - MOVING PARTS

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts.

Stay away from moving parts to prevent serious injuries. When test cycling the actuator and valve assembly by applying pressure to the A or B port, be aware that there are moving parts like pinion top, actuator to valve coupling and the valve- blade, ball, plug, etc.

### NOTICE


The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers. For the removal of inserts, a special extractor tool can be supplied on request.

During assembly to the valve, do not hit with hammer on pinion top. This can damage the pinion top washer and cause premature failure.

Before mounting the actuator on the valve or valve bracket, be sure that both the actuator and the valve are in the same closed or open position.


Refer to appendix B, Tool and Torque tables, for using the right size tool

**Table 7. Tool Table**

Symbol	Tool	Symbol	Tool
	Wrench – All types and sizes. Metric and Imperial		Phillips -H- screw driver for actuator sizes 0025 to 0600.
	Circlip Pliers		Allen key for actuator size 0012


1. Remove handle nut, handle, lock washer, and etc. from the valve if required.
2. Visually check to make sure the valve is CLOSED.

**Figure 9 Valve handle removal**




- When required, check if the insert drive (23) is mounted. If not, use a plastic mallet and tap slightly until the reducer square is in the required position. Be sure that the insert is mounted at 90° or 45°. It is possible to mount the insert turned 22.5°. This way the valve will not open or close the right way.

Figure 10 Insert drive Installation



- Install the bracket to the valve flange. Tighten all bolts and nuts and apply the correct torque.

Figure 11 Bracket Installation



5. Install the actuator to the bracket. Tighten all bolts and apply the correct torque (refer to Table 8).

**Table 8. Bottom flange torque values**

Actuator Size	ISO Pattern	Thread	Torque (Nm)	
			Min.	Max.
25	3 inner pattern	M5	2.0	3.0
	5 outer pattern	M6	4.5	5.0
40, 65, 100	5 inner pattern	M6	4.5	5.0
	7 outer pattern	M8	10.5	12.5
150, 200, 350	7 inner pattern	M10	21.0	24.5
	F10 outer pattern	M10	27.0	24.5
600	F10 inner pattern	M10	21.0	24.5
	F12 outer pattern	M12	34.5	43.0
950, 1600, 2500, 4000				


6. When required, mount or adjust the visual indicator (22).

**Figure 12 Indicator mounting**

"In Line mounting"



"Across Line mounting"



## 4.6 Mounting of control and feedback accessories

Solenoid valve and or switch boxes can now be mounted to the actuator. Check the instructions as shipped with these components for installation, operating and maintenance instructions.

We recommend to test-cycle the complete assembly to check correct operation.

## 4.7 Recommended Tubing Sizes

In case the solenoid valve is mounted remotely (i.e. in a central solenoid cabinet) and in order to supply sufficient flow of air supply to the actuator, the following tubing sizes are recommended.

**Table 9. Tubing Sizes**

Actuator size	Runs up to		Runs over to	
	1.2 meters	4 feet	1.2 meters	4 feet
25, 40, 65	6 mm	1/4 inch	6 mm	1/4 inch
100, 150, 200, 350, 600	6 mm	1/4 inch	8 mm	5/16 inch
950, 1600, 2500, 4000	6 mm	1/4 inch	10 mm	3/8 inch

## Section 5: Mechanical Stroke Adjustment

This section explains:

- What mechanical stroke adjustment is.
- What the factory settings are.
- How to adjust the travel stops.


EL-O-Matic F actuator sizes 25 to 4000 have two stroke adjustment stops for adjusting accurately the stroke of the actuator/valve assembly in open and closed position.

The smallest actuator, size F12, does not have limit stops.

The factory setting of the stroke is 90°. Most quarter-turn valve applications will not require readjustment of these settings.

If required the stroke can be adjusted by means of two-stroke adjustment bolts.

**Figure 13** Factory Setting



## 5.1 Travel Stop Adjustment

### ⚠ CAUTION - PRESSURIZED ACTUATOR


Do not turn out the travel stops completely when the actuator is pressurized.

When adjusting the travel stops and the actuator is still pressurized, the travel stops can be "shot" away when completely turned out.

### 5.1.1 Double-Acting Actuators

1. Operate valve/actuator assembly to the required "Closed" position.
2. Remove air supply.
3. Slacken locknut on the "closed" stop (2).

Figure 14




4. Turn the "closed" stop clockwise to reduce or counterclockwise to increase the travel. Consult chapter 5.1.3 (angular displacement of the pinion), to define how far the limit stop must be turned in or out.
5. Tighten the lock nut.
6. Connect air and cycle the actuator to check that the position is correct. If not repeat from 2.
7. Remove air supply.
8. For adjusting the open position repeat steps 1 to 7, but now for the open position and "open" stop (1).

### 5.1.2 Spring-Return Actuators

1. Connect air supply to the A port. Actuator will move to the open position.
2. Slacken locknut (24) on the "closed" stop (2).

Figure 15



3. Turn the "closed" stop clockwise to reduce or counterclockwise to increase the travel. Consult chapter 5.1.3 (angular displacement of the pinion), to define how far the limit stop must be turned in or out.
4. Remove air supply. Actuator will move to the closed position.
5. Check whether the actuator valve assembly is in the required position. If not repeat steps 1 to 5.
6. Remove air supply.
7. For adjusting the open position repeat steps 1 to 6, but now for the open position and "open" stop (1).

**Table 10. Limit stop dimensions**

Actuator size	Thread	Bolt Wrench	Nut wrench
		size (mm)	size (mm)
25	M 6	10	10
40	M 8	13	13
65	M 10	17 (16)*	17 (16)*
100	M 10	17 (16)*	17 (16)*
150	M 10	17 (16)*	17 (16)*
200	M 12	19 (18)*	19 (18)*
350	M 16	24	24
600	M 20	30	30
950			
1600			
2500			
4000			

1. Default dimension according DIN933 standard.
2. Dimensions in brackets according ISO4017 standard.
3. Actuator size 12 is not available with limit stops.

### 5.1.3 Angular Displacement

Below table identifies, per actuator size, what the angular displacement of the pinions is, when using the limit stop screws.

- Turn the limit stop clockwise reduces the stroke
- Turn the limit stop counterclockwise to increase the stroke

**Table 11. Angular Displacement**

Actuator size	Turns for 5° adjustment of the pinion:	360° revolution of limit stop screw will adjust
F 12	Actuator size 12 is not available with limit stops	
F 25	0.7	7.1°
F 40	0.8	6.3°
F 65	0.6	8.3°
F 100	0.7	7.1°
F 150	1.2	4.2°
F 200	1.0	5.0°
F 350	0.8	6.3°
F 600	0.8	6.3°
F 950		
F 1600		
F 2500		
F 4000		

#### **NOTICE**

In case of air leakage over the limit stop bolts, turn the lock nut of the limit stop bolts tighter, until leakage stops.

## Section 6: Maintenance

This section explains:

- When and how to do maintenance.
- What to do when replacing springs.
- What the availability is of spare parts, action conversion kits and temperature conversion kits.

### **⚠ WARNING**

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembling the actuator consult the relevant sections of this manual.

## 6.1 General

EL-O-Matic F actuators are designed to operate without maintenance for their normal working life. Normal working life is 500,000 cycles.\*

We recommend regular inspections to make certain that the actuator / valve assembly operates smoothly and to check that there are no visible or audible defects.

Replacement of internal seals and bearings allows to you extend the normal working life. Repair kits, containing all necessary seals bearings, grease and instructions can be obtained through authorized Emerson Process Management – Valve Automation distributors.

All actuators are supplied with sufficient lubrication for their normal working life. If required, see section 9.1 (Grease instructions) for the recommended grease.

For mounting the parts of the repair kit follow the instruction of the Decommission, Disassembly and Reassembly chapters of this manual.

#### **Note:**

\*Cycles = one open stroke and one close stroke.

## 6.2 Repair

### 6.2.1 Spring-Return actuator

On spring-return actuators, the spring cartridges can be replaced. **SPRING CARTRIDGES SHOULD ALWAYS BE REPLACED IN COMPLETE SETS.** Spring kits are available through authorized Emerson Process Management – Valve Automation distributors.

### 6.2.2 Recommended Spare Parts

All soft seals, bearings, and nonreusable parts are included in the recommended spare parts kit. The spare parts kit is identical for both the double-acting and the spring-return models. For the spring-return models we recommend a set of spare springs for each different model in addition to the recommended spare parts kit.

## Section 7: Decommission (Out of Service)

This section explains:

- How to decommission an actuator in a safe way.

### 7.1 Before You Start

#### **⚠ WARNING - MOVING PARTS**

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembling the actuator consult the relevant sections of this manual.

Actuator can move when removing supply pressure and/or electrical control signal of actuators. If not already there, a spring-return actuator will cycle to its fail position.

When removing any ball valve or plug valve assemblies from a pipe system, isolate the piping system on which the Actuator is installed and relieve any media pressure that may be trapped in the valve cavities before removing the actuator for maintenance.

A spring-return actuator mounted on a valve, which is stuck in mid stroke, contains a high spring load which will cause a sudden rotation of the actuator versus the valve or valve bracket during disassembly. This can cause serious injury to personnel or damage to property.

Refer to Appendix A for instructions to safely remove the spring load before disassembling the spring-return actuator from valve or bracket.

---

#### **Important**


Refer to the Safety Guide for Lifting Instructions.

---

## 7.2 Removing the actuator from the valve

1. Disconnect all air supply hoses (Ports A and B or solenoid).
2. Disconnect all electrical wirings of the switch box.
3. Disconnect the electrical wiring of the solenoid valve.
4. Remove the bolts and nuts from the valve flange.
5. Remove the bracket from the actuator.
6. Remove the switch box and solenoid valve. Refer to the documentation of the switch box and solenoid valve for safe disassembly.

Figure 16 Removing actuator from valve



## Section 8: Disassembly

This section explains:

- How to disassemble an actuator safely.

---

### Tip

The instructions of this section can be used for maintenance or reconfiguration like spring set change or maintenance.

Reference numbers for components refer to the exploded view in section 11.

In case of maintenance, discard all the used soft parts like O-ring seals, guide bands, wear strips and circlip.

---

### **⚠ WARNING**

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts.

Before mounting or (dis)assembling the actuator consult the relevant sections of this manual.

---

### **⚠ CAUTION - SPRING FORCE**

Spring-return actuators contain springs in a compressed state. Follow these instructions to release the spring force safely.

Normally the end caps of spring-return actuators should be free of the spring load after 10 full turns (crosswise relaxing) of the end cap screws. If there is still spring load on the end cap, this might indicate a broken spring cartridge. Stop this disassembly procedure immediately. Continuing might cause the end cap to be "shot" away causing serious injury.

Refer to Appendix A for instructions to safely remove the spring load before disassembling the end cap of a spring-return actuator with a broken spring cartridge.

---

### **NOTICE**

The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers.


Refer to the tables in this section or refer to appendix B Tool and Torque tables.

---

## 8.1 Removing End Caps

1. For Double-acting actuators, do the following:
  - a. Loosen the screws (10) of the end caps (2).
  - b. Remove the o-ring (14) and "B" port seal (16). Discard these parts.

**Figure 17 Double-Acting End Caps Removal**




The above end caps (2) are for Actuator sizes 25, 40, 65 and 100.

End caps (2) for Actuator sizes 150 and larger will have flat end caps (see below).



2. For Spring-return actuators, do the following:
  - a. **Tip:** For actuators with assembly code CW, turn back the right hand limit stop screw (17) 2 full turns.  
For actuators with assembly code CC, turn back the left hand limit stop screw (17) 2 full turns.  
This will lower the spring force on the end cap and reduces the screw out length of the end cap screws.
  - b. **Important:** Apply a strong, sudden rotational and downward force to loosen all the end cap screws (10) for maximum 1/4 turn.
  - c. Uniformly loosen the screws (10) of the end caps (2) 1/4-1/2 turns at a time, in sequence, as per figure 18, to relieve the pre-load of the springs.
  - d. Remove the o-rings (14) and "B" port seals (16). Discard these parts.


Figure 18 Spring-Return End Caps Removal



## 8.2 Removing Spring Cartridges (Spring-Return)

1. Remove the spring cartridges (5).


Figure 19



## 8.3 Removing of Limit Stop

1. Remove the limit stop screws (17), limit stop nuts (18), limit stop washers (19) and limit stop o-rings (15). Discard the o-rings.


Figure 20 Limit Stop Removal



## 8.4 Removing Pistons

1. Use a wrench and turn the pinion counterclockwise (180°) until the pistons (3) comes out of the body.
2. Remove the piston bearings (7), piston rack bearing strips (6) and piston o-ring seals (13). Discard these parts.

Figure 21 Piston Removal



## 8.5 Removing pinion

1. Remove the circlip (11) and thrust washer (9) on top of the pinion assembly. Discard if necessary the circlip (11) and thrust washer (9).
2. Remove the pinion (4) by pushing it downwards.
3. Remove the pinion o-ring seals (12) and the pinion bearings (8). Discard all of these parts.

Figure 22 Pinion Removal




Table 12. Recommended circlip pliers according DIN 5254 (or equal) for shaft circlips.

Actuator size	Pinion top diameter		Pliers according DIN 5254
12	16 mm	0.630"	A1
25 - 100	22 mm	0.866"	A2
150 - 350	36 mm	1.417"	A3
600	55 mm	2.165"	A3

## 8.6 Cleaning the Body

In case of maintenance, use a clean dry cloth and thoroughly wipe clean and remove old grease from:

- The inside and outside of the body including thread holes and crevices/grooves
- The pinion gears
- The pistons

## Section 9: Reassembly

This section explains:

- Which parts and how to grease them.
  - How to reassemble a complete actuator.
  - How to set the stroke adjustment bolts after reassembly.
  - How to do a basic function and air leak test.
- 

### Tip

The instructions of this section can be used for maintenance or reconfiguration like spring set change or maintenance.

Reference numbers for components refer to the exploded view in section 11.

In case of maintenance, discard all used soft parts like O-ring seals, guide bands and wear strips and circlip and replace them with the parts as supplied in the repair kit.

In case of reconfiguration replace the parts as supplied in the conversion kit (see also chapter 6).

Refer to the Safety Guide for Lifting Instructions.

---

### **NOTICE**

The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers.

Refer to the tables in this section or refer to appendix B Tool and Torque tables.

---

## 9.1 Grease Instructions

Check the product coding on the product labels and chapter 3 of this manual, to define which type of grease to use.


- For standard actuators (-20°C to +80°C / -4°F to +176°F):  
Castrol High Temperature grease (or equivalent).
- For low temperature operation (-40°C to +80°C / -40°F to +176°F):  
Castrol Optitemp TT1 grease (or equivalent).
- For high temperature operation (-20°C to +120°C / -4°F to +248°F):  
Castrol High Temperature grease (or equivalent).

We recommend using a suitable sized paint brush to apply the required amount of grease on the parts as per Table 12 and Figure 23.

**Table 13. Grease Instructions**

Part		Section of part	Amount of grease
O-rings:	A	Completely	Light film
Housing Parts:	B	Piston bore	Light film
	C	Top pinion bore	Light film
	D	Bottom pinion bore	Light film
Piston Parts:	E	O-ring & bearing groove	Light film
	F	Rack teeth	Half the teeth depth full with grease
	G	Piston bearing	Light film on outside
	H	Piston rack bearing strip	Light film
Piston Parts:	J	Pinion bottom & O-ring groove	Light film
	K	Pinion top & O-ring groove	Light film
	L	Gear teeth	Half the teeth depth
	M	Pinion top bearing	Light film (inside and out)
	N	Pinion bottom bearing	Light film (inside and out)


**Figure 23 Grease Instructions**



## 9.2 Reassembly of the pinion

1. Grease the pinion parts according to chapter 9.1.
2. Install the pinion bearings (8) and the O-ring seals (12) on the pinion (4).
3. Insert the pinion (4) on the housing.
4. Install the thrust washer (9) and mount the circlip (11) on the pinion top using circlip pliers.
  - Install the new circlip onto its mating groove on the top shaft extension and with the non-sharp edge (2) towards the housing and the sharp edge (1) towards the top of the shaft.

**Figure 24** Reassemble the pinion



**Table 14.** Recommended circlip pliers according DIN 5254 (or equal) for shaft circlips.

Actuator size	Pinion top diameter		Pliers according DIN 5254
12	16 mm	0.630"	A1
25 - 100	22 mm	0.866"	A2
150 - 350	36 mm	1.417"	A3
600	55 mm	2.165"	A3


## 9.3 Reassembly of the pistons

### NOTICE

Before reassembling the pistons, check the required assembly code (see section 4.2).


1. Grease the piston parts according to step 9.1.
2. Install the piston bearings (7), piston rack bearing strips (6) and piston o-ring seals (13) on the pistons. Ensure all these parts are kept in place during assembly.

Figure 25 Reassemble the pistons



3. Align the pinion (see Figure 26) so that the teeth on the pinion will pick up the pistons rack teeth when turning the pinion. Note the position of the pinion top slot and the cam on the pinion top:
  - For standard or Spring-to-Close: Assembly Code CW
  - For reverse or Spring-to-Open: Assembly Code CC
4. Slightly push the pinion inward to engage with the pinion.
  - Ensure that smooth movement and 90-degree operation can occur without moving the pistons out of the actuator body.
  - For larger pistons, use a rubber mallet and slightly hitting the pistons inward to engage with the pinion.
5. When the pistons are moved 90° inwards (see figure 26), check that the pinion slot on the pinion top is:
  - Perpendicular to the length centre line of the house for assembly code CW.
  - In line to the length centre line of the house for assembly code CC.
6. If not, turn pinion to move the pistons outward until they disengage from the pinion. Shift one tooth of the pinion, reassemble and check again.

Figure 26 Position of the slot and the cam on the pinion top



- A = Position of cam
- B = Position of slot and in dot in pinion
- C = Final position of pinion dot


**Note:**

When the pistons are completely moved inwards, the pinion top will show a 5° over travel.

## 9.4 Reassembly and settings of the limit stops

1. Install the limit stop screws (17), limit stop nuts (18), limit stop washers (19) and limit stop o-rings (15).

Figure 27 Install Limit Stop Bolts




2. Move the pistons inward until the slot in the top of the pinion is perpendicular to centerline of the housing.
3. Double check if the position of the slot and the cam on the pinion top is in the correct position (see figure 26). Screw in the right hand travel stop until it comes into contact with the pinion stop face.
4. Move the pistons outward until the slot in the top of the pinion is in line with the centerline of the housing.
5. Screw in the left hand travel stop until it comes into contact with the pinion stop face.
  - For accurate travel stop adjustment of the actuator on the valve, see section 5.

## 9.5 Reassembly of the end caps

### 9.5.1 Double-Acting actuators

1. Grease the O-ring seals (14) and B port seals (16) according to step 9.1.
2. Ensure that O-ring seals (14) and B port seals (16) are kept in place during assembly.
3. Install the end caps (2) and tighten the end cap screws (10). Refer to Table 14 for the correct torque.

Figure 28 Double-acting end cap assembly



The above end caps (2) are for Actuator sizes 25, 40, 65 and 100.

End caps (2) for Actuator sizes 150 and larger will have flat end caps (see below).



Table 15. End cap Screw Torque

Actuator size	Thread	Tool	Size	Torque (Nm)			Torque (lbf.ft)		
				Target	Min.	Max.	Target	Min.	Max.
12	M4	Allen key	SW 3	1.1	0.8	1.3	0.8	0.6	1.0
25	M5	Phillips -H- Screwdriver	No. 2	2.0	1.6	3.0	1.5	1.2	2.2
40	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
65	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
100	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
150	M6		No. 3	3.3	2.6	5.1	2.4	1.9	3.8
200	M6		No. 3	3.3	2.6	5.1	2.4	1.9	3.8
350	M8		No. 4	8.4	6.7	12.2	6.2	4.9	9.0
600	M10	No. 4	15.3	12.2	24.8	11.3	9.0	18.3	
950									
1600									
2500									
4000									

## 9.5.2 Spring-Return actuators


### Important

When replacing spring cartridges in a spring-return actuator, ensure that the cartridges are replaced in their identical position from where they were removed.

Check below figure to see where to place the spring cartridges in case of spring set conversion.

Before assembling the spring cartridges and end caps, make sure that the pistons are completely inwards.


Figure 29 Spring cartridge placement



A = Piston top view  
B = Position of gear rack

1. Grease the O-ring seals (14) and B port seals (16) according to step 9.1.
2. Ensure that O-ring seals (14) and B port seals are kept in place during assembly.
3. Place the spring cartridges in actuator as per required spring set (see Figure 29).
4. Tighten each end cap screw in small equal turns and in the sequence as per Figure 28. Refer to Table 13 for the correct torque. We recommend to use some grease on the screws for easier fastening.

Figure 30 Spring-return end cap assembly




## 9.6 Basic function and Air Leak Test

### ⚠ CAUTION - MOVING PARTS

Applying pressure to the actuator will cause the actuator/valve assembly to operate.

1. Apply pressure (max. 8 bar/116 psi) to ports A and B. Use some soap suds at the indicated points: around pinion top (1), pinion bottom (2), the end caps (3) and limit stops (4).
2. In case of leakage around:
  - a. The limit stop bolts (and/or the spring-package bolt at spring-return models). Turn the lock nut of the bolts tighter; until the leakage stops.
  - b. The end caps: Disassemble the end caps, replace o-rings and reassemble.
  - c. The pinion top or bottom and A- or B- port: Disassemble the complete actuator, replace o-rings and reassemble.

Figure 31 Basic function and air leak test



# Section 10: Troubleshooting

## 10.1 Mechanical Problems

Problem	Possible error	Solution	Where to find
Feedback position and actual position are not the same	Actuator and valve are mounted 90° rotated in relation to each other.	Remove actuator from valve. Check assembly code of actuator. Put both valve and actuator in "Closed" position. Mount actuator on valve.	Section 4
Valve is in "Closed" position, actuator is in "Open" position and will not move anymore.			
Valve does not reach the completely "Closed" or "Open" position.	Limit stop screws are not set correctly.	Readjust the limit stop screws.	Section 5
	Insert is not mounted properly.	Mount the insert in the right position. Remark: Rotate insert to one cam = 22.5°.	Section 4.5
	Pressure too low.	Apply pressure as per sizing.	
	Sizing is wrong.	Check valve torque data with actuator torque data.	
	Pinion is mounted in the wrong position	Reassemble actuator.	Section 9
Actuator rotates, valve does not.	No coupling between actuator shaft and valve spindle.	Install a coupling between actuator shaft and valve spindle.	Section 4.5

## 10.2 Pneumatic Problems

Problem	Possible error	Solution	Where to find
Actuator does not react to electrical control signal.	There is no supply pressure at the actuator.	Supply the right pressure to the actuator.	Section 2.3 Check that the actual supply pressure is higher than the sizing pressure.
Actuator does not react good to electrical control signal.	There is sufficient supply air pressure but insufficient supply air capacity.	Take care the supply air tubing has the right dimensions.	Section 4.6
	Supply pressure too low, causing pilot operated solenoid valve to fail.	Check that supply pressure at the actuator and solenoid is sufficient to operate the actuator.	Section 2.3 Check that the actual supply pressure is higher than the sizing pressure.
	Solenoid valve is not mounted properly.	Check the solenoid valve mounting.	Instructions shipped with the solenoid valve.
	Speed control throttle (if present) blocks air flow.	Turn the speed control more open.	Instructions shipped with the speed control valve.
	Manual override (if present) on the Solenoid Valve is locked.	Unlock manual override on the solenoid valve.	Instructions shipped with the manual override.
Air leakage between actuator and solenoid valve.	Sealing between solenoid valve and actuator is not mounted air tight.	Reassemble solenoid valve taking care, that all seals are in place.	Instructions shipped with the solenoid valve.
Double-acting actuator will only move to "open" position.	Actuator has wrong solenoid valve configuration.	Mount a solenoid valve suitable for double-acting actuators (4/2 or 5/2 function).	Instructions shipped with the solenoid valve.
		Check that conversion plate on solenoids, that have both 3/2 and 5/2 functions, is in the right position.	Instructions shipped with the solenoid valve.

## 10.3 Electrical Problems

Problem	Possible error	Solution	Where to find
Actuator does not react to control signals.	Control wiring. Power supply wiring or feedback wiring are not right connected.	Connect all wiring in the right way.	Instructions of the control or feedback accessories.
	The power supply voltage is not is not the same as the voltage of the applicable solenoid valve.	Connect the right power supply voltage.	Instructions of the solenoid valve.
There are problems with position feedback after sending the actuator to either the "Open" or "Closed" position.	The wiring of the feedback signals may be switched.	Connect the feedback wiring in the right way.	Instructions of the feedback device.

# Section 11: Parts List and Spare Parts Recommendations

## 11.1 Exploded View and Parts List




Table 16. Parts List

Pos.	Qty		Description	Material
1	1		House	Cast Aluminium alloy
2	2		End cap	Cast Aluminium alloy
3	2		Piston	Cast Aluminium alloy
4	2		Pinion	High grade aluminium
5	Max. 12		Spring cartridge	Spring steel
6	2	*	Bearing strip piston rack	POM
7	2	*	Bearing piston	PTFE 25% carbon-filled
8	2	*	Bearing pinion	POM
9	1	*	Thrust washer	POM, black UV stabilized
10	8		End cap screw	Stainless Steel
11	1	*	Circlip	Spring steel
12	2	*	O-ring seal pinion	Nitrile rubber
13	2	*	O-ring seal piston	Nitrile rubber
14	2	*	O-ring seal end cap	Nitrile rubber
15	2	*	O-ring seal limit stop	Nitrile rubber
16	2	*	B-port seal	Silicon rubber
17	2		Limit stop screw	Stainless steel
18	2		Limit stop nut	Stainless steel
19	2		Limit stop washer	PA66
20	2		Warning sticker	Polyester
21	1		Indicator assembly	ABS + stainless steel screw
22	1		Center plate (option)	Nylon PA6, Black
23	1		Insert drive	Aluminium

\* = included in repair kit

## Appendix A: Spring load removal

This section explains:

- How to remove the spring load safely of spring-return actuators in case:
  - The valve gets “stuck” in mid position.
  - One of the spring cartridges is broken.

### ⚠ WARNING - MOVING PARTS

A spring-return actuator mounted on a valve, which is stuck in mid stroke, contains a high spring load which will cause a sudden rotation of the actuator versus the valve during disassembly. This can cause serious injury to personnel or damage to material.

On spring-return actuators with a broken spring cartridge, the end cap can be “shot” away during disassembly of the actuator. This can cause serious injury to personnel or damage to material.

## A.1 Spring load relief

### ⚠ CAUTION - ROTATING ACTUATOR

In case of an actuator/valve assembly “stuck” in mid position, leave the actuator on the valve and/or mounting bracket during this procedure.

Figure A-1 Spring load removal




1. Depressurize the actuator completely.
2. Based on the actuator size, choose the correct threaded rod kit from Table A-1.
3. Replace one by one each end cap screw for the threaded rod kit and turn down the adjusting nut until it touches the end cap.
4. Once all for end cap screws have been replaced, gradually turn the adjustment nuts on threaded rod in CCW direction by turning the nuts half turn at a time. Make sure the rod itself does not turn. Continue this until the load of springs are relieved.
5. Repeat the same procedure for the end cap screws on the other size of the actuator as shown in figure A-1.
6. In case of an actuator/valve assembly “stuck” in mid position: The actuator now can be disassembled from Valve, by removing the mounting studs/bolts.

**Table A-1. Threaded rod dimensions in mm**

Actuator Size	Thread	Threaded rod length	
		(mm)	(inch)
12	M4	132	5.2
25	M5	140	5.5
40	M5	140	5.5
65	M5	140	5.5
100	M5	140	5.5
150	M6	145	5.7
200	M6	145	5.7
350	M8	185	7.3
600	M10	185	7.3
950			
1600			
2500			
4000			

**Figure A-2 Spring load removal rod dimensions**



## Appendix B: Tool & Torque Table

This section explains:

- Which tools to use for the indicated fasteners
- The recommended amount of torque to apply on the indicated fasteners.

**Table B-1. End cap bolts**

Actuator size	Thread	Tool	Size	Torque (Nm)			Torque (lbf.ft)		
				Target	Min.	Max.	Target	Min.	Max.
12	M4	Allen key	SW 3	1.1	0.8	1.3	0.8	0.6	1.0
25	M5	Phillips -H- Screwdriver	No. 2	2.0	1.6	3.0	1.5	1.2	2.2
40	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
65	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
100	M5		No. 2	2.0	1.6	3.0	1.5	1.2	2.2
150	M6		No. 3	3.3	2.6	5.1	2.4	1.9	3.8
200	M6		No. 3	3.3	2.6	5.1	2.4	1.9	3.8
350	M8		No. 4	8.4	6.7	12.2	6.2	4.9	9.0
600	M10		No. 4	15.3	12.2	24.8	11.3	9.0	18.3
950									
1600									
2500									
4000									

**Table B-2. Bottom flange**

Actuator size	ISO Pattern	Metric	Torque (Nm)		Imperial	Torque (lbf.ft)	
		Thread	Min.	Max.	Thread	Min.	Max.
12	4	M6	4.5	5.0	10-24UNC	3.3	3.7
25	3 inner pattern	M5	2.0	3.0	10-24UNC	1.5	2.2
	5 outer pattern	M6	4.5	5.0	1/4"-20	3.3	3.7
40, 65, 100	5 inner pattern	M6	4.5	5.0	1/4"-20	3.3	3.7
	7 outer pattern	M8	10.5	12.5	5/16"-18	7.7	9.2
150, 200, 350	7 inner pattern	M8	10.5	12.5	5/16"-18	7.7	9.2
	F10 outer pattern	M10	21.0	24.5	3/8"-16	15.5	18.1
600	F10 inner pattern	M10	21.0	24.5	3/8"-16	15.5	18.1
	F12 outer pattern	M12	34.5	43.0	1/2"-13	25.4	31.7
950	F10 inner pattern	M10			3/8"-16		
	F14 outer pattern	M16			5/8"-11		
1600	F16 inner pattern	M20			3/4"-10		
	F25 <sup>1</sup> outer pattern	M16			5/8"-11		
2500	F16 inner pattern	M20			3/4"-10		
	F25 <sup>1</sup> outer pattern	M16			5/8"-11		
4000	F16 inner pattern	M20			3/4"-10		
	F25 outer pattern	M16			5/8"-11		

1. For actuator sizes 1600 and 2500 only 4 holes of the ISO5211 F25 drilling pattern are available.

**Table B-3. NAMUR (VDE/VDI 3845) flanges**

Flange	Metric	Torque (Nm)		Imperial	Torque (lbf.ft)	
	Thread	Min.	Max.	Thread	Min.	Max.
Solenoid flange screw threads	M5	2.0	3.0	10-24UNC	1.5	2.2
Top flange screw threads	M5	2.0	3.0	10-24UNC	1.5	2.2

**Table B-4. Limit stop screws and nuts**

Actuator size	Thread	Bolt Wrench	Nut wrench
		size (mm)	size (mm)
25	M 6	10	10
40	M 8	13	13
65	M 10	17 (16) <sup>1</sup>	17 (16) <sup>1</sup>
100	M 10	17 (16) <sup>1</sup>	17 (16) <sup>1</sup>
150	M 10	17 (16) <sup>1</sup>	17 (16) <sup>1</sup>
200	M 12	19 (18) <sup>1</sup>	19 (18) <sup>1</sup>
350	M 16	24	24
600	M 20	30	30
950			
1600			
2500			
4000			

Default dimension according DIN933 standard  
Dimensions in brackets according ISO4017 standard  
Actuator size 12 is not available with limit stops

**Table B-5. Recommended circlip pliers according DIN 5254 (or equal) for shaft circlips**

Actuator size	Pinion top diameter		Pliers according DIN 5254
F12	16 mm	0.630"	A1
F25 - F100	22 mm	0.866"	A2
F150 - F350	36 mm	1.417"	A3
F600	55 mm	2.165"	A3

World Area Configuration Centers (WACC) offer sales support, service, inventory and commissioning to our global customers. Choose the WACC or sales office nearest you:

**NORTH & SOUTH AMERICA**

19200 Northwest Freeway  
Houston, TX 77065  
T +1 281 477 4100  
F +1 281 477 2809  
Av. Hollingsworth,  
325, Iporanga Sorocaba,  
SP 18087-105  
Brazil  
T +55 15 3238 3788  
F +55 15 3228 3300

**ASIA PACIFIC**

No. 9 Gul Road  
#01-02 Singapore 629361  
T +65 6501 4600  
F +65 6268 0028

No.1 Lai Yuan Road  
Wuqing Development Area  
Tianjin 301700  
P.R.China  
T +86 22 8212 3300  
F +86 22 8212 3308

**MIDDLE EAST & AFRICA**

P. O. Box 17033  
Dubai  
United Arab Emirates  
T +971 4 811 8100  
F +971 4 886 5465

P. O. Box 10305  
Jubail 31961  
Saudi Arabia  
T +966 3 340 8650  
F +966 3 340 8790

24 Angus Crescent  
Longmeadow Business Estate  
East P.O. Box 6908; Greenstone;  
1616 Modderfontein, Extension 5  
South Africa  
T +27 11 451 3700  
F +27 11 451 3800

**EUROPE**

Asveldweg 11  
7556 BR Hengelo (O)  
The Netherlands  
T +31 74 256 1010  
F +31 74 291 0938

For complete list of sales and manufacturing sites, please visit [www.emersonprocess.com/valveautomationlocations](http://www.emersonprocess.com/valveautomationlocations) Or contact us at [info.valveautomation@emerson.com](mailto:info.valveautomation@emerson.com)

[www.emersonprocess.com/elomatic](http://www.emersonprocess.com/elomatic)

All Rights Reserved.

We reserve the right to modify or improve the designs or specifications of the products mentioned in this manual at any time without notice. Emerson Process Management does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson Process Management product remains solely with the purchaser.

©2014 Emerson Electric Co.

