

OPERATING INSTRUCTIONS

Single Channel Hall Effect Speed Sensor DSF xx10.xx MxV / PxV / SxV



Product ID

Type #	Product #	Drawing #
DSF 1210.00 MTV (5m)	374Z-03970	4-111.478
DSF 1210.00 MTV (L=m)	374Z-03971	4-111.478
DSF 1210.00 SHV (2m)	374Z-03869	4-110.428
DSF 1210.00 SHV (30m)	374Z-03879	4-110.428
DSF 1210.00 SHV (5m)	374Z-03880	4-110.428
DSF 1210.00 SHV (L=m)	374Z-03924	4-110.428
DSF 1210.00 STV (5m)	374Z-03870	4-110.428
DSF 1210.00 STV (L=m)	374Z-03923	4-110.428
DSF 1210.01 PHV (0,36m)	374Z-04903	3-112.475
DSF 1210.06 PHV	374Z-05512	3-114.319 Rev.3
DSF 1410.00 SHV (2m)	374Z-03927	4-111.496
DSF 1410.00 SHV (5m)	374Z-03928	4-111.496
DSF 1410.00 SHV (L=m)	374Z-03929	4-111.496
DSF 1410.00 STV (5m)	374Z-03925	4-111.496
DSF 1410.00 STV (L=m)	374Z-03926	4-111.496
DSF 1410.00 STV S148	374Z-03890	3-110.687 S148
DSF 1410.01 SHV (10m)	374Z-04218	4-111.809
DSF 1610.00 MTV S151	374Z-03966	4-110.794 S151
DSF 1610.00 SHV (2m)	374Z-03932	4-111.498
DSF 1610.00 SHV (5m)	374Z-03933	4-111.498
DSF 1610.00 S1HV (5m)	3742610332	122743
DSF 1610.00 STV (5m)	374Z-03930	4-111.498
DSF 1810.00 MTV (5m)	374Z-03976	4-111.481
DSF 1810.00 SHV (2m)	374Z-03871	4-110.687
DSF 1810.00 SHV (5m)	374Z-03882	4-110.687
DSF 1810.00 SHV (L=m)	374Z-03936	4-110.687
DSF 1810.00 SHV S162	374Z-04210	4-110.687 S162
DSF 1810.00 STV (5m)	374Z-03872	4-110.687
DSF 1810.00 STV (L=m)	374Z-03935	4-110.687
DSF 1810.02 PTV (0,4m)	374Z-04941	4-112.558
DSF 1810.03 PHV S12 (0,6m)	374Z-05255	4-113.349
DSF 1810.10 SHV	374Z-05884	115.773 Rev.0

Continued on the next page.



OPERATING INSTRUCTIONS

Type #	Product #	Drawing #
DSF 2210.00 MTV (5m)	374Z-03978	4-111.482
DSF 2210.00 MTV (L=m)	374Z-03979	4-111.482
DSF 2210.00 SHV (2m)	374Z-03874	4-110.777
DSF 2210.00 SHV (5m)	374Z-03877	4-110.777
DSF 2210.00 SHV (L=m)	374Z-03938	4-110.777
DSF 2210.00 STV (5m)	374Z-03875	4-110.777
DSF 2210.00 STV (6m)	374Z-03876	4-110.777
DSF 2210.00 STV (L=m)	374Z-03937	4-110.777
DSF 2210.87 MHV (5m)	374Z-04849	111482A Rev.01
DSF 2210.87 MHV S22 (5m)	374Z-05684	111482A Rev.01
DSF 2210.87 PHV	374Z-05372	3-113.742
DSF 2210.87 STV (5m)		
(old type: FTG 1087.00 S)	374Z-03853	4-111037
DSF 2210.87 STV S166 (10m)	374Z-04781	4-109604s166
DSF CD10.00 SHV (2m)	374Z-05392	4-113.862
DSF EH10.00 STV (5m)	374Z-04360	4-111.915
DSF EH10.08 P1HV	374Z-05028	112.778 Rev.1
DSF EH10.08 SHV (5m)	374Z-04836	4-112.350
DSF EH10.11 SHV (2m)	374Z-05073	4-112.914
DSF EH10.15 SHV (5m)	374Z-05511	4-114.317 Rev.3
DSF EH10.16 SHV	374Z-05716	115.031 Rev.0



OPERATING INSTRUCTIONS

General	
Function	The sensors DSF are suitable, in conjunction with a pole wheel, for generating square wave signals proportional to rotary speeds. They have a dynamic behaviour, so that pulse generation is guaranteed down to a speed corresponding to a frequency of 0.05 Hz. The monitoring elements consist of a
	magnetically biased hall effect semiconductor followed by a short-circuit proof push-pull output stage. The sensor function is independent on the rotational orientation of the sensor axis.
Certification	The DSF sensors are approved by Germanischer Lloyd (GL): Certificate 17332-00 HH
Technical data	
Supply voltage	10 V to 30 V, protected against transient overvoltages and reverse polarity
Current consumption	Max. 16 mA (without load)
Signal output	Square wave Bush will autout a land 100 mm
	 Push-pull outputs: I_{max} = ± 20 mA with pull-up resistor (for I= I_{max}): U_{low} < 2.5 V, U_{high} > 0.95 * U_{supply}
	o with pull-down resistor (for I= I_{max}). $U_{low} < 2.3 \text{ V}$, $U_{high} > 0.93 U_{supply}$
	 The outputs are short circuit proof and protected against reverse polarity.
Frequency range	0.05 Hz 20 kHz
Electromagnetic	According to Directive 2004/108/EC, EN 61000-6-2 and 61000-6-4:
compatibility (EMC):	• Electrostatic discharge into housing, cable shield and wires: up to ±4 kV peak
	according to IEC 61000-4-2, severity level 2
	 Radiated electromagnetic field: up to 30 V/m, 50% AM, 1 kHz in the range of 1 MHz to 1000 MHz according to IEC 61000-4-3, severity level 3
	Fast electrical transients/bursts, coupled to sensor cable with a capacitive
	coupling clamp: up to ±4 kV peak according to IEC 61000-4-4, severity level 4
Housing	Stainless steel 1.4305, front side sealed hermetically and resistant against
	splashing water, oil, conducting carbon- or ferrous dust and salt mist. Electronic
	components potted in chemical and age proof synthetic resin. Max. allowable
	pressure on sensor head: 10 bar Dimensions according to drawing.
	Differsions according to drawing.
	Max. tightening torque:
	12 Nm for M12x1 25 Nm for M14x1 35 Nm for M16x1
	50 Nm for M18x1 75 Nm for M22x1
Requirements for pole wheel	Toothed wheel of a magnetically permeable material (e.g. Steel 1.0036) Optimal performance with
	Involute gear
	• Tooth width > 10 mm
	• Side offset < 0.2 mm
	Eccentricity < 0.2 mm
Air gap between sensor and	Air gap between pole wheel (involute gear) and sensor housing:
pole wheel	• Module 1: 0.21.0 mm
	Module 2: 0.22.5 mmModule 3: 0.23.5 mm
	 Module 3: 0.23.5 mm Module 4 and coarser: 0.24.5 mm
Insulation	Housing and electronics galvanically separated (500 V/50 Hz/ 1 min)
Protection class	IP68 (head) and IP67 (cable outlet)
Vibration immunity	5 g in the range of 5 2000 Hz
Shock immunity	50 g for 20 ms, half sine wave
Temperature	Operating temperature of sensor:
	Version H: -40° +125℃
	• Version T: -25° +85°C
D. P. 199	Check properties of cable and protective conduits.
Reliability	The following MTTF and failure rates were computed based on Siemens
	SN29500 and valid for an operating temperature of 60°C. They include the electrical failure modes but not the mechanical.
	Glootheal latitie modes but not the mechanical.
	MTTF [hours] Failure rate [FIT]
	3'177'000 314.8



OPERATING INSTRUCTIONS

Connection type

Sensor type	Connection type	Jaquet part number
7,1	Cable with protective	824L-35665 (cable)
DSF 1210.00 MTV (5m)	conduit	825G-36148 (conduit)
	Cable with protective	824L-35665 (cable)
DSF 1210.00 MTV (L=m)	conduit	825G-36148 (conduit)
DSF 1210.00 SHV (2m)	Cable	824L-35053
DSF 1210.00 SHV (30m)	Cable	824L-35053
DSF 1210.00 SHV (5m)	Cable	824L-35053
DSF 1210.00 SHV (L=m)	Cable	824L-35053
DSF 1210.00 STV (5m)	Cable	824L-35665
DSF 1210.00 STV (L=m)	Cable	824L-35665
	Cable with	824L-33024 (cable)
DSF 1210.01 PHV (0,36m)	integrated connector	820P-36527 (connector)
	Cable with	824L-35053 (cable)
DSF 1210.06 PHV	integrated connector	820A-36859 (connector)
DSF 1410.00 SHV (2m)	Cable	824L-35053
DSF 1410.00 SHV (5m)	Cable	824L-35053
DSF 1410.00 SHV (L=m)	Cable	824L-35053
DSF 1410.00 STV (5m)	Cable	824L-35665
DSF 1410.00 STV (L=m)	Cable	824L-35665
DSF 1410.00 STV S148	Cable	824L-35665
DSF 1410.01 SHV (10m)	Cable	824L-35053
	Cable and cable	824L-35665 (cable)
DSF 1610.00 MTV S151	gland	CF-Pg9 (cable gland)
DSF 1610.00 SHV (2m)	Cable	824L-35053
DSF 1610.00 SHV (5m)	Cable	824L-35053
DSF 1610.00 S1HV (5m)	Cable	824L-35053
DSF 1610.00 STV (5m)	Cable	824L-35665
	Cable with protective	824L-35665 (cable)
DSF 1810.00 MTV (5m)	conduit	825G-30924 (conduit)
DSF 1810.00 SHV (2m)	Cable	824L-35053
DSF 1810.00 SHV (5m)	Cable	824L-35053
DSF 1810.00 SHV (L=m)	Cable	824L-35053
DSF 1810.00 SHV S162	Cable	824L-35053
DSF 1810.00 STV (5m)	Cable	824L-35665
DSF 1810.00 STV (L=m)	Cable	824L-35665
	Cable with	824L-35053 (cable)
DSF 1810.02 PTV (0,4m)	integrated connector	820A-36859 (connector)
DSF 1810.03 PHV S12	Cable with	824L-35053 (cable)
(0,6m)	integrated connector	820E-37235 (connector)
DSF 1810.10 SHV (L=2m)	Cable	824L-35053

Continued on the next page.



OPERATING INSTRUCTIONS

Connection type (continued)

Sensor type	Connection type	Jaquet part number
	Cable with protective	824L-35665 (cable)
DSF 2210.00 MTV (5m)	conduit	825G-30924 (conduit)
	Cable with protective	824L-35665 (cable)
DSF 2210.00 MTV (L=m)	conduit	825G-30924 (conduit)
DSF 2210.00 SHV (2m)	Cable	824L-35053
DSF 2210.00 SHV (5m)	Cable	824L-35053
DSF 2210.00 SHV (L=m)	Cable	824L-35053
DSF 2210.00 STV (5m)	Cable	824L-35665
DSF 2210.00 STV (6m)	Cable	824L-35665
DSF 2210.00 STV (L=m)	Cable	824L-35665
	Cable with protective	824L-35053 (cable)
DSF 2210.87 MHV (5m)	conduit	825G-36356 (conduit)
DSF 2210.87 MHV S22	Cable with protective	824L-32832 (cable)
(5m)	conduit	825G-36356 (conduit)
		824L-36622 (cable)
	Cable with integrated	820E-35207
DSF 2210.87 PHV	connector	(connector)
DSF 2210.87 STV (5m)	Cable	824L-31081
DSF 2210.87 STV S166		
(10m)	Cable	824L-31081
DSF CD10.00 SHV (2m)	Cable	824L-35053
DSF EH10.00 STV (5m)	Cable	824L-35665
		824L-32832 (cable)
	Cable with integrated	820P-36963
DSF EH10.08 P1HV	connector	(connector)
DSF EH10.08 SHV (5m)	Cable	824L-35053
DSF EH10.11 SHV (2m)	Cable	824L-36222
DSF EH10.15 SHV (5m)	Cable	824L-35053
DSF EH10.16 SHV	Cable	824L-35053

Cables

Jaquet cable type	Properties
	PE/PVC cable, 3-wire, 0.75 mm ² , outer- Ø max.
	7.3 mm, bending radius min. 110 mm, screened (metal
	net), gray
824L-31081	Operating temperature: -30℃ to +70℃
	FEP cable, 3-wire, 0.75 mm² (AWG 19), outer-Ø max.
	5.9 mm, bending radius min. 85 mm, screened (metal
	net), black
824L-32832	Operating temperature: -90℃ to +200℃
	PTFE cable, 3-wire, 0.6 mm ² (AWG 20), outer-Ø max.
	4.7 mm, bending radius min. 70 mm, screened (metal
	net), white
824L-33024	Operating temperature: -90℃ to +260℃
	FEP cable, 4-wire (brown wire is not connected), 0.2
	mm² (AWG 24), outer-Ø max. 4.2 mm, bending radius
	min. 60 mm, screened (metal net), white
824L-35053	Operating temperature: -100℃ to +150 ℃
	PVC cable, 3-wire, 0.23 mm ² (AWG 24), outer-Ø max.
	4.2 mm, bending radius min. 60 mm, screened (metal
	net), grey
824L-35665	Operating temperature: -20℃ to +80℃
	FEP cable, 4-wire (white wire is not connected), 0.6
	mm ² (AWG 20), outer-Ø max. 4.7 mm, bending radius
	min. 24 mm, screened(metal net), white
824L-36222	Operating temperature: -60℃ to +150 ℃
	Silicone cable, 6-wire, 0.6mm ² , outer- Ø max.
	13.0 mm, bending radius min. 30 mm, screened (metal
	net), black
824L-36622	Operating temperature: -40℃ to +150℃



OPERATING INSTRUCTIONS

Connectors

Jaquet connector code	Manufacturer code
	Escha WASS4
	Plug-and-socket connection: IP67
820A-36859	Operating temperature: -30℃ to +90℃
820E-35207	GB60-18-11 Sn-EAA, 5-pole
820E-37235	ITT Cannon CA06COM-PG-14S-2P-B-01-F0
	AMP 282105-1
	Plug-and-socket connection: IP67
820P-36527	Operating temperature: -40℃ to +125℃
	Deutsch DT06-3S-EP06
	Plug-and-socket connection: IP67
820P-36963	Operating temperature: -40℃ to +125℃

Protective conduit

Jaquet code	Properties
	Cold strip DC 03 acc. to EN 10139, galvanized,
	Fe/Zn3, sheating: PVC
	Weatherproof, watertight, highly resistant to seawater,
	acids and oils, free of silicone and cadmium, very
	flexible, stretch resistant, crush resistant, dark grey
825G-30924	Operating temperature: -25℃ to +80℃
	Cold strip DC 03 acc. to EN 10139, galvanized,
	Fe/Zn3, sheating: Polyurethan (PU)
	Absolutely oil- benzine- and grease resistant, widely
	resistant to solvents and acids, free of halogen,
	silicone and cadmium, high tenacity and abrasion
	resistance, very flexible, microbic resistant, flame
	resistant, metallic blue
825G-36148	Operating temperature: -40℃ to +100℃
	Cold strip DC03 acc. to EN 10139 galvanized
	Highly flexible, stretch resistant, lateral crush resistant,
	outer-Ø 14.0 mm, bending radius min. 34 mm
825G-36356	Operating temperature: -60℃ to +220℃



OPERATING INSTRUCTIONS

Further Information	
Safety	All mechanical installations must be carried out by an expert. General safety requirements have to be met.
Connection	The sensors must be connected according to sensor drawing. Sensor wires are susceptible to radiated noise. Therefore, the following points have to be considered when connecting a sensor: The sensor wires must be laid as far as possible from large electrical machines. They must not run parallel in the vicinity of power cables. The maximum permissible cable length is dependent upon the sensor voltage, the cable routing, along with cable capacitance and inductance. However, it is advantageous to keep the distance between sensor and instrument as short as possible. The sensor cable may be lengthened via a terminal box located in an IP20 connection area in accordance with EN 60529.
Installation	The sensor has to be aligned to the pole wheel according to the sensor drawing. Deviations in positioning may affect the performance and decrease the noise immunity of the sensor. During installation, the smallest possible pole wheel to sensor gap should be set. The gap should however be set to prevent the face of the sensor ever touching the pole wheel. A sensor should be mounted with the middle of the face side over the middle of the pole wheel. Dependent upon the wheel width, a certain degree of axial movement is permissible. However, the middle of the sensor must be at minimum in a distance of 3 mm from the edge of the pole wheel under all operating conditions. A solid and vibration free mounting of the sensor is important. Eventual sensor vibration relative to the pole wheel can induce additional output pulses. The sensors are insensitive to oil, grease etc. and can be installed in arduous conditions. Within the air gap specified the amplitude of the output signals is not influenced by the air gap. Particular mounting instructions for: • DSF 1610.00 MTV S151: The detecting element is placed on the lateral side of the sensor housing (see dimensional drawing). Its position is marked on the surface. The applicable maximal air gap is reduced by 0.6 mm with respect to the data mentioned in this operating instructions. At the cable output of the housing a protective conduit can be mounted around
	the sensor cable. This is not part of the delivery.
Maintenance	Product cannot be repaired.
Transport	Product must be handled with care to prevent damage of the front face.
Storage	Product must be stored in dry conditions. The storage temperature corresponds to the operation temperature.
Disposal	Product must be disposed of properly, it must not be disposed as domestic waste.