

Microprocessor - based controller μ Celsitron baelz 6490 / baelz 6590
Universal three - position step controller



Industrial controller with special PID - step controller algorithm



- | | |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------|
| <input type="checkbox"/> Easy operation | <input type="checkbox"/> Two adjustable setpoints |
| <input type="checkbox"/> User - defined operating level | <input type="checkbox"/> Remote setpoint |
| <input type="checkbox"/> Digital displays for process variable and setpoint | <input type="checkbox"/> Setpoint ramp |
| <input type="checkbox"/> Control structure PI and PID | <input type="checkbox"/> Control via digital inputs |
| <input type="checkbox"/> Two - position control | <input type="checkbox"/> Serial interface |
| <input type="checkbox"/> Three - position control | <input type="checkbox"/> Robust self - optimization |
| <input type="checkbox"/> Measurement inputs for Pt 100, current and voltage signals | <input type="checkbox"/> Semi - conductor memory for data protection |
| <input type="checkbox"/> Manual -/ automatic changeover | <input type="checkbox"/> Plug - type terminals |
| <input type="checkbox"/> Compact design 96mm x 96mm x 135mm | <input type="checkbox"/> Degree of protection Front IP 65 |
| | <input type="checkbox"/> Compact design 48mm x 96mm x 140mm |

Rights reserved to make technical changes!

Contens

1. Function overview.....	3
2. Operating and setting	4
2.1 Setting setpoint in automatic mode	4
2.2 Opening / closing actuator in manual mode.....	4
2.3 Branch to parameterization -/ configuration level.....	5
2.4 Branch to second operating level (user - defined operating level).....	6
2.5 Set parameters / configuration points.....	6
3. Parameterization -/ configuration level.....	7
3.1 Optimization for automatic determination of favourable control parameters.....	7
3.2 Proportional band Pb.....	10
3.2.1 Three - position controller.....	10
3.3 Integral action time t_n	10
3.3.1 Two - position controller.....	10
3.4 Derivative action time t_d	10
3.5 Dead band db	10
3.6 Actuating time t_P (Valve actuation time).....	10
3.7 Alarm (at 6490 /0 /1 /2 and 6590 /0 /1 /2).....	11
3.8 Alarm relays (at 6490 /3 /4 /5 and 6590 /3 /4 /5).....	12
3.9 Decimal point for LED - displays	15
3.10 Scaling the process variable display PV	15
3.11 Setpoint limitation.....	15
3.12 Remote -/ local changeover (at 6490 /1 /2 /5 and 6590 /1 /2 /5).....	15
3.13 Second setpoint SP.2 (at 6490 /2 /3 /4 and 6590 /2 /3 /4).....	15
3.14 Setpoint ramp SP.r	16
3.15 Ramp direction.....	16
3.16 Process Gain P.G.....	16
3.17 Input for process variable PV (input PV).....	17
3.18 Input for remote setpoint SP (input SP) (at 6490 /1 /2 /5 and 6590 /1 /2 /5).....	17
3.19 Measured value filter for process variable PV	17
3.20 Response to sensor failure PV (sensor break).....	17
3.21 Interlocking manual -/ automatic changeover (manual).....	17
3.22 Direction of action of controller.....	18
3.23 Function of the digital inputs (Open, Close, Stop) (at 6490 /3 /4 and 6590 /3 /4).....	18
3.24 Transmitting speed for serial interface (baud) (at 6490 /3 /4 and 6590 /3 /4).....	18
3.25 Address for serial interface (at 6490 /3 /4 and 6590 /3 /4).....	18
3.26 Serial communication (at 6490 /3 /4 and 6590 /3 /4).....	18
3.27 Second operating level (operating level 2).....	19
3.28 Access to the parameterization / configuration level (password).....	19
4. Mounting.....	20
5. Electrical connection.....	20
5.1 Wiring diagram	21
6. Commissioning.....	22
7. Technical data	23
8. Ordering number baelz 6490 / baelz 6590	24
9. Overview of parameterization -/ configuration level, data list.....	25

**Warning:**

During electrical equipment operation, the risk that several parts of this unit will be connected to high voltage is inevitable. Improper use can result in serious injuries or material damage.

The warning notes included in the following sections of these operating instructions must therefore be observed accordingly. Personnel working with this unit must be properly qualified and familiar with the contents of these operating instructions.

Perfect, reliable operation of this unit presupposes suitable transport including proper storage, installation and operation.

1. Function overview

Basic device

Analog input Pt100
 Analog input 0/2 to 10V
 Analog input 0/4 to 20mA
 Relay OPEN
 Relay CLOSE
 Relay ALARM 1 and ALARM 2

The analog inputs can be used optionally as a process variable input PV or as an input for an analog, remote setpoint SP

Controller output OPEN, opens the controlling element
 Controller output CLOSE, closes the controlling element
 Selectable alarm. The alarm relay operates on the basis of the normally closed contact principle.

Digital input REM/LOC
 Supply voltage 24 V DC

For remote -/ local selection
 For two-wire transmitter and digital inputs

Additional functions (option*)


Serial interface RS 485
 Process variable output 0 to + 10 V

Data transfer in accordance with MODBUS protocol
 Only with Pt 100 as process variable sensor PV

Digital input OPEN
 Digital input CLOSE
 Digital input STOP
 Digital input REM/LOC
 Digital input SP.2

The actuator opens
 The actuator closes
 The actuator stops in its current position
 For remote -/ local selection
 To change over to second setpoint SP.2
 - connecting 24V DC to the corresponding digital input
 - priority: 1. Stop 2. Close 3. Open 4. SP.2 5. Rem/Loc 1. = highest priority

} not in manual mode



Block diagram

-  Setpoint limitation minimum value SP.L - setpoint low, maximum value SP.H - setpoint high. Only setpoints within the setpoint limits can be set by way of the keyboard.
-  Setpoint ramp SP.r. The setpoint change per minute (gradient) can be specified for local and remote setpoints with the aid of the setpoint ramp.
-  Filtering FIL of the process variable input PV. Interference signals and small process variable fluctuations can be smoothed by an adjustable software filter.
-  * Digital inputs, voltage range 0 / 12 - 24 V DC Internal or external voltage source possible.
-  * Serial interface

2. Operating and setting

Alarm

Operating level::

- Actuator opens
- Actuator closes
- 2nd setpoint effective, setpoint 2 or Alarm 2
- Setpoint ramp active
- Remote setpoint effective, or serial communication remote setpoint
- Manual mode




Process variable display

Setpoint display
Other phys. units available as stickers


At the device 6590 the same designations for the adequate functions are valid, only the positioning differs.

2.1 Setting setpoint in automatic mode




Setting range: SP.L to SP.H
Locked setpoint input at SP.2 or REM. and S.C = 1

2.2 Opening / closing actuator in manual mode



2.3 Branch to parameterization -/ configuration level




P ⏳ >2s press longer than 2s

without password (see also: 3.28: PAS)




first configuration point

with password without second operating level (see also: 3.27: OL.2)




first configuration point



set password invalid password:
back to operating level

valid password
see page 26: PAS / Cod


with password with second operating level




second operating level (see also 3.27: OL.2)

* if selected for the user - defined operating level

1) device with serial interface



first configuration point



set password invalid password:
back to operating level


valid password
see page 26: PAS / Cod

P ⏳ >2s Back to operating level possible at any time

Manual -/ automatic changeover possible at any time

2.4 Branch to second operating level (user - defined operating level)

Parameters and configuration points that have been selected for the second operating level (see also 3.27: OL.2) can be called up and set without entering the password, in case access to the parameterization -/ configuration level is protected by a password



(see also 3.28: PAS).


*if this function has been selected for the user-defined operating level and the access to the parameterization -/ configuration level has been interlocked by means of the password.

1) device with serial interface

The following can be set as an option on the second operating level:


- self-optimization OPt
- alarm AL.,HYS
- remote -/ local changeover r.EL or serial communication S.C
- second setpoint SP.2
- setpoint ramp SP.r

2.5 Set parameters / configuration points




3. Parameterization -/ configuration level


3.1 Optimization for automatic determination of favourable control parameters..



- a change in the setpoint SP (not for remote setpoint)
- a change in the setpoint SP.2 on the parameterization -/ configuration level, if SP.2 is the effective setpoint (see also 3.13: SP.2)
- a changeover from manual to automatic mode



Optimization from manual mode



Optimization in automatic mode

Procedure during optimization:

From the manual mode:

- Set the setpoint SP
- Switch over to manual mode
- Set the process variable PV greater / smaller than the setpoint SP by opening / closing the controlling element (a)
- Wait until PV is stable (b)
- Branch to parameterization -/ configuration level
- Set OPt = "1"
- If known, enter process gain P.G. (standard setting: P.G = 100%)
- Back to operating level
- Switch over to automatic mode

In the automatic mode:

- Wait until PV is stable (b)
- Branch to parameterization -/ configuration level
- Set OPt = "1"
- If known, enter process gain P.G. (standard setting: P.G = 100%)
- Back to operating level
- Set the setpoint

Self - optimization starts upon manual -/ automatic changeover (for optimization from the manual mode) or upon setpoint change δ SP (for optimization in the automatic mode). During the optimization procedure, the **tunE** display is shown cyclically in the setpoint display SP. The determined parameters (P_b , t_n , T_d , P.G) are accepted automatically at the end of the self - optimization procedure.



The optimisation routine will not be started, if the control deviation X_w (manual mode) or the setpoint change δ SP (automatic mode) is less than 3.125% of the measuring range PV at the beginning of the optimization procedure. The change in the process variable PV or the setpoint must, during optimization, run in the same range and in the same direction in which the process is controlled following optimization, which means that the optimization procedure must correspond to the later control procedure as far as possible. If, during a control process, sequences of the process show extreme differences in time behaviour (e.g. rapid heating, slow cooling), the more important part of the process should be optimized. If the process sequences are equivalent, the slower procedure has to be optimized.

For systems with linear transfer behaviour (constant process gain $P.G = \frac{\delta PV}{\delta Y}$ over the entire control range), one optimization procedure will always provide the optimum control parameters.

If the transfer behaviour of the system is non-linear (e.g. process gain $P.G = \frac{\delta PV}{\delta Y}$ changes with the setpoint SP to be controlled), the variable process gain P.G will have a significant effect on the control parameters. In this case, the process variable PV should come close to achieving the target setpoint during the optimization procedure.

Otherwise, an additional optimization procedure must be carried out. The process gain P.G in the working point was determined automatically in the preceding optimization procedure.

If the process gain P.G in the working point is known, it can be entered manually prior to optimization. (see also 3.15: P.G).

The configuration point OPT is reset to 0 automatically following each optimization procedure.

An optimization procedure can be interrupted anytime by pressing the hand - key or the P - key briefly.

NO ENTRIES OR CHANGEOVER OPERATIONS MUST BE MADE DURING THE OPTIMIZATION PROCEDURE !

Additional explanations for self-optimization of three - position step controllers

The optimization of a temperature control with a low initial temperature and a higher final temperature serves as an example.

- **The temperature difference of the initial temperature and the aim temperature must be more than 12.5 °C.**

(At Pt100- measuring range 2.2: 0 to 400 °C, more than 12.5 °C

at Pt100-measuring range 2.4: 0 to 300 °C; more than 9.5 °C)

But it is more favourable, if there is a larger difference between initial temperature and final temperature.

If heat - up action is optimized the initial temperature should correspond to the temperature of the cold plant, the aim temperature to the setpoint of the temperature control.

- **The temperature should be stable before starting the optimization.**

For that purpose set the controller's setpoint to the initial temperature and wait until the temperature has balanced at this value. Actual value and setpoint do not have to be equal absolutely.

If the controller is not able to keep the initial temperature stable in automatic mode, e.g. in case of temperature oscillation the initial temperature has to be adjusted in manual mode.

Position the motorized valve via the CLOSE - key and the OPEN - key to reach the initial temperature approximately.

- **At beginning of optimization the motorized valve must not be closed completely.**

- **The optimization is started at changing the setpoint or at change - over from manual mode to automatic mode.**

Assumption: configuration point OPT = -1-

- **At beginning of optimization the controller automatically opens the motorized valve for a certain amount.**
How far the motor valve is opened depends on the difference of actual value and aim setpoint and of the adjusted process gain P.G (initial value P.G = 100%)
The motorized valve remains in this position up to the end of optimization.
Always check the position displacement on site at the motorized valve.
- **During optimization the motorized valve must not be opened completely.**
The stroke of the control valve must be smaller than 95%.
Check the position of the motorized valve on site.
- **The opening of the motorized valve causes a rise of temperature.**
Depending on the amount of temperature rise and its temporal progress the controller determines the parameters proportionalband Pb, integral action time tn, derivative action time td and the real progress gain P.G.
- **The controller automatically finishes the optimization as soon as the temperature is balanced on the higher value.**
The parameters are calculated at the end of optimization.
- **The controller ceases the optimization if the temperature is not yet balanced on the higher value after 42 minutes.**
Ceasing the optimization, no parameters are determined.
This break is possible in plants with a very slow time behaviour.
This break is possible in plants without balance
(e.g. continuous rise of temperature at constant valve position, temperature drift)
- **In these cases optimization can be finished manually by switching over configuration point OPt from -1- to -0- within 42 minutes.**
The parameters are calculated when configuration point OPt is switched over from -1- to -0-
A manually finished optimization delivers favourable parameters
 - in plants with slow time behaviour, if the temperature approached the stable final value but did not yet reach it entirely. The approachment to a stable end-value is recognized by the strong reduction of speed in change of temperature as against to the first half of the optimization - time.
 - in plants with continuous temperature drift (no stable initial - and final temperature) if the rate of temperature rise during optimization is essentially higher than during the normal temperature drift. Optimization is ceased manually when temperature rise slides over to normal temperature drift
- **Therefore optimization can also be started if the temperature is not balanced before optimization but has a continuous drift rate.**
In this case optimization has to be finished manually (see above).
- **The change of temperature during optimization must be more than 25% of the difference between actual value and setpoint (difference at start of optimization).**
With smaller temperature changes no parameters are determined at the end of optimization.
- **If the change of temperature is too small, the setting of the parameter P.G (process gain) has to be decreased manually and afterwards a further optimization has to be done.**
This causes a larger change of temperature during the following optimization.
- **If the change of temperature during optimization is too large and optimization is interrupted manually (overtemperature) the setting of the parameter P.G (progress gain) has to be increased manually.**
This causes a smaller change of temperature during the following optimization.
- **If the temperature does not approximately reach the aim setpoint at the end of optimization (possible in plants with unlinear transfer behaviour) a further optimization is convenient.**
The controller runs through a learning process and determines the real process gain P.G. During the next optimization actual value and setpoint come closer together.

3.2 Proportional band Pb

Setting range: 1.0 % to 999.9%
Proportional action of the PI(D) three - position step controller


3.2.1 Three - position controller

by settings: $Pb = 0.0$
 $tn > 0$

Control action adjustable via dead band db.



(see also 3.5: db)



3.2.1 Three - position Controller

3.3 Integral action time tn


Setting range: 1s to 2600s
Integral action of the PI(D) three - position controller

3.3.1 Two - position controller

by setting $tn = 0$

Control action adjustable via dead band db.

(see also 3.5: db)



3.3.1 Two position controller

3.4 Derivative action time td

Setting range: 1 to 255s
Derivative action of the PID three - position step controller
By setting $td = 0$: PI three - position step controller




3.5 Dead band db

Setting range: 0 to extent of measuring range
[phys. units] ($\times 0,1$ at $dP = 0$)
Hysteresis: $db/2$

No control pulses at control deviation smaller db.

(see also 3.2.1 three - position controller
3.3.1 two - position controller)



3.5 Dead band

3.6 Actuating time t.P (Valve actuation time)

Setting range: 5s to 300s
Time to pass through the correcting range 0 to 100 % (stroke) at constant OPEN or CLOSE - pulse





3.7 Alarm (at 6490 /0 /1 /2 and 6590 /0 /1 /2)

The alarm relay operates on the basis of the normally closed contact principle.



Selection AL = 0:

No alarm, also not in case of sensor failure (see also 3.20: SE.b)



Selection AL = 1:

Alarm at a limit value based on the setpoint SP (Type A).
and in case of sensor failure.

Alarm at $SP \pm AL.=$

Setting range: 0 to \pm extent of measuring range [phys. units].



Alarm hysteresis HYS,

reset hysteresis of alarm relay

Setting range: 0 to extent of measuring range [phys. units] (x 0,1 at dp = 0)



Selection AL = 2:

Alarm at fixed limit value (Type B).
and in case of sensor failure.

Alarm at $AL.-$

Setting range: measuring range [phys. units]



Alarm hysteresis HYS,

reset hysteresis of alarm relay

Setting range: 0 to extent of measuring range [phys. units] (x 0,1 at dp = 0)

Selection AL = 3:

Alarm at leaving a band by the setpoint SP (Type C).
and in case of sensor failure

Alarm at $SP - AL.=$ and $SP + AL.=$



Lower band half :

setting range: 0 to - extent of measuring range [phys. units]

Alarm at $SP - AL.=$



Alarm hysteresis HYS (-),

lower band half, reset hysteresis of alarm relay.
Setting range: see before



Upper band half :


setting range: 0 to + extent of measuring range [phys. units]

Alarm at $SP + AL.=$




Alarm hysteresis HYS (+),

upper band half, reset hysteresis of alarm relay. Setting range: see before.




Selection AL = 1 (Type A)

In case of sensor failure: Alarm independent of the adjusted limit value



Selection AL = 2 (Type B)

In case of sensor failure: Alarm independent of the adjusted limit value



Selection AL = 3 (Type C)

In case of sensor failure: Alarm independent of the adjusted limit band



3.8 Alarm relays (at 6490 / 3 / 4 / 5 and 6590 / 3 / 4 / 5)

The alarm relays operate on the basis of the normally closed contact principle.

3.8.1 Alarm Type A

Alarm at a limit value based on the setpoint SP

3.8.1.1 Alarm 1 at $SP \pm AL_{\neq}$

3.8.1.2 Alarm 2 at $SP \pm AL_{=}$


Setting range: 0 to \ddot{Y} extend of measuring range [phys. unit]

Reset hysteresis of alarm relays:

3.8.1.3 End of alarm 1 at $SP \pm AL_{\neq} \pm s HYS$ (HYS displayed after AL_{\neq})

3.8.1.4 End of alarm 2 at $SP \pm AL_{=} \pm s HYS$ (HYS displayed after $AL_{=}$)

Setting range: 0 to extend of measuring range [phys. unit] (x 0,1 at dp = 0)



3.8.2 Alarm Type B

Alarm 1 at a fixed limit value


3.8.2.1 Alarm 1 at AL_{-}

Setting range: measuring range \ominus phys. unit \ominus

Reset hysteresis of alarm relay 1:

3.8.2.2 End of alarm 1 at $AL_{-} - HYS$ (HYS displayed after AL_{-})

Setting range: 0 to extend of measuring range \ominus phys. unit \ominus (x 0,1 at dp = 0)



Alarm Type B for alarm relay 1

3.8.3 Alarm Typ C

Alarm 1 at leaving a band by the setpoint SP.


3.8.3.1 Alarm 1 at $SP \pm AL_{\neq}$ and at $SP \pm AL_{=}$ (s. also 3.8.1.1, 3.8.1.2)

Setting range: 0 to \ddot{Y} extend of measuring range [phys. unit]

Reset hysteresis of alarm relay 1:

3.8.3.2 End of alarm 1 at $SP \pm AL_{\neq} \pm s HYS$ and $SP \pm AL_{=} \pm s HYS$ (see also 3.8.1.3, 3.8.1.4)

Setting range: 0 to \ddot{Y} extend of measuring range [phys. unit] (x 0,1 at dp = 0)



Alarm Type C for alarm relay 1

Selection AL = 0:

No alarms, also not in case of sensor failure (see also 3.20: SE.b)

Selection AL = 1: (Alarm relay 1 active)

AL=

Alarm relay 1 = Type A (see also 3.8.1.1)

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

HYS

Reset hysteresis of alarm relay 1 (see also 3.8.1.3)

Selection AL = 2: (Alarm relay 1 active)

AL-

Alarm relay 1 = Type B (see also 3.8.2.1)

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

HYS

Reset hysteresis of alarm relay 1 (see also 3.8.2.2)

Selection: AL = 3: (Alarm relay 1 and Alarm relay 2 active)

AL=

Alarm relay 1 = Type A (see also 3.8.1.1)

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

HYS

Reset hysteresis of alarm relay 1 (see also 3.8.1.3)

AL-

Alarm relay 2 = Type A (see also 3.8.1.2)

HYS

Reset hysteresis of alarm relay 2 (see also 3.8.1.4)

Selection: AL = 4: (Alarm relay 1 and Alarm relay 2 active)

AL-

Alarm relay 1 = Type B (see also 3.8.2.1)

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

HYS

Reset hysteresis of alarm relay 1 (see also 3.8.2.2)

AL=

Alarm relay 2 = Type A (see also 3.8.1.2)

HYS

Reset hysteresis of alarm relay 2 (see also 3.8.1.4)

Selection: AL = 5: (Alarm relay 1 and Alarm relay 2 active)

AL=

Alarm relay 1 = Type C (see also 3.8.3.1)

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

Reset hysteresis of alarm relay 1 at AL.= (see also 3.8.3.2)

HYS

Alarm relay 1 = Type C (see also 3.8.3.1)

AL-

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

Alarm relay 2 = Type A (see also 3.8.1.2)

Reset hysteresis of alarm relay 1 at AL.= (see also 3.8.3.2)

Reset hysteresis of alarm relay 2 (see also 3.8.1.4)

HYS

Selection: AL = 6: (Alarm relay 1 and Alarm relay 2 active)

AL-

Alarm relay 1 at AL.- or at SP ± AL.=

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

Reset hysteresis of alarm relay 1 at AL.- (see also 3.8.2.2)

HYS

Alarm relay 1 at AL.- or at SP ± AL.=

AL=

Alarm relay 1 in case of sensor failure independent of the adjusted setpoint.

Alarm relay 2 = Type A (see also 3.8.1.2)

Reset hysteresis of alarm relay 1 at AL.= (see also 3.8.1.4)


HYS

Reset hysteresis of alarm relay 2 (see also 3.8.1.4)

selection	alarm 1	alarm 2
0	-	-
1	A	-
2	B	-
3	A	A
4	B	A
5	A1 v A2 (C)	A
6	B v A2	A
sensor break	alarm	no alarm

v = logical OR


Alarm types for alarm relay 1 and alarm relay 2



3.9 Decimal point for LED - displays

Selections: 0 Indication without decimal point
1 Indication with decimal point

At any time the decimal point has been altered, the process variable display PV has to be rescaled. (see also 3.10: dI.L, dI.H)



3.10 Scaling the process variable display PV

Display.Low Enter: Zero point of the transmitter
Indication at the LED - Display PV at start of measuring range
Setting range: $-999 (-99.9 \text{ at } dP = 1) \leq dI.L \leq dI.H-1$ [phys. units] (dI.L must be less than dI.H)
standard value: **0° C** or **32° F**

Display.High Enter: End point of the transmitter
Indication at the LED - Display PV at end of measuring range
Setting range: $dI.L+1 \leq dI.H \leq 9999 (999.9 \text{ at } dP = 1)$ [phys. units] (dI.H must be greater than dI.L)
standard value: **300° C** or **572° F**


At In.P = 0, dI.L and dI.H have to correspond to the Pt 100 - measuring range of the supplied device (see type plate)

baelz 6490 / 6590 - 2.4 - ... : dI.L = 000(.0), dI.H = 300(.0)
baelz 6490 / 6590 - 2.2 - ... : dI.L = 000(.0), dI.H = 400(.0)


At In.P = 0, dI.L and dI.H have to correspond to the measuring range of the connected transmitter. (see also 3.17: In.P)

3.11 Setpoint limitation

Setpoint limitation applies to the setpoint SP which can be set via the keyboard
It is ineffective for - the second setpoint SP.2
- all remote setpoints




Setpoint.Low lowest setpoint that can be set
Setting range: dI.L to SP.H [phys. units] (see also 3.10: dI.L)
At SP.L = SP.H the setpoint has a fixed value.
Effective for the setpoint entered via the keyboard.



Setpoint.High highest setpoint that can be set
Setting range: SP.L to dI.H [phys. units] (see also 3.10: dI.H)
At SP.L = SP.H the setpoint has a fixed value.
Effective for the setpoint entered via the keyboard.


3.12 Remote -/ local changeover (at 6490 /1 /2 /5 and 6590 /1 /2 /5)



Changeover from remote to local setpoint and vice versa
At devices without serial interface.
Remote / Local Setpoint remote = external, local = internal

Selections: 0 only local setpoint and SP.2 effective
1 Changeover via digital input REM/LOC, setpoint via analog input (see also 3.18: In.S)
2 jolt - free (smooth) remote -/ local changeover by tracking the local setpoint to the remote setpoint before remote -/ local changeover. SP loc. = SP rem. otherwise as 1
In case of a signal error the internal setpoint is effective.

3.13 Second setpoint SP.2 (at 6490 /2 /3 /4 and 6590 /2 /3 /4)




Setting range: dI.L to dI.H [phys. units] (see also 3.10: dI.L, dI.H)
Changeover to SP.2 via digital input SP.2

SP.r

P

3.14 Setpoint ramp SP.r

Change rate of setpoint SP (gradient)
 Setting range: 1 (0.1 at dP = 1) to extent of measuring range in PV / min; PV [phys. unit]
 e.g.: K / min
 Setting SP.r = 0: no setpoint ramp, change of setpoint abruptly.
 Effective for local and remote setpoints.
 An analog, remote setpoint has to alter at least 0.2 % of measuring range PV to trigger the setpoint ramp.



3.14 Setpoint ramp SP.r

The setpoint ramp is triggered

- after switching on the device or after a power failure
- after sensor failure
- after every setpoint change (remote, local or SP.2)
- after switching over to the second setpoint SP.2
- after remote -/ local changeover and vice versa
- after a control function STOP, CLOSE, OPEN (via digital input)
- after switching over from manual mode to automatic mode

The start point of the setpoint ramp is always the current value of the process variable PV (a)
 The current setpoint is displayed.

rA.d

P

3.15 Ramp direction

Effective direction of setpoint ramp SP.r (at SP.r > 0)

Selections:

- 0 Setpoint ramp effective for increasing and decreasing setpoints
- 1 Setpoint ramp effective only for increasing setpoints
- 2 Setpoint ramp effective only for decreasing setpoints (see also 3.14: SP.r)

P.G

P

3.16 Process Gain P.G

Setting range: 1 to 255%

$$\text{Gain of controlled process (system) } P.G = \frac{\text{Change in process variable PV}}{\text{Change in actuating variable Y}} = \frac{8 \text{ PV}}{8 \text{ Y}} \text{ in \%}$$

8 PV [% of measuring range of PV]
 8 Y [% of actuating range (stroke) 0 - 100 %]

e.g.: P.G = 50%: $\frac{8 \text{ PV}}{8 \text{ Y}} = 0,5$

A change of 10% in the valve position 8Y will result in a change of 5% in the process variable PV.


P.G = 100%: $\frac{8 \text{ PV}}{8 \text{ Y}} = 1,0$

A change of 10% in the valve position 8Y will result in a change of 10% in the process variable PV.

P.G = 125%: $\frac{8 \text{ PV}}{8 \text{ Y}} = 1,25$

A change of 10% in the valve position 8Y will result in a change of 12.5% in the process variable PV.


The process gain P.G is required for self - optimization of the control parameters. If unknown, P.G is determined automatically during self - optimization (see also: 3.1: OPT)
 In case of non - linear transfer behaviour of the system, the process gain changes with the working point (e.g. when controlling different setpoints).



3.17 Input for process variable PV (input PV)

Selections:

- 0 PV is detected with a Pt100 sensor and connected to the terminals 14, 15, 16
 - 1 PV is supplied as current signal 0-20 mA and connected to the terminals 12, 16*.
 - 2 PV is supplied as current signal 4-20mA and connected to the terminals 12, 16*.
 - 3 PV is supplied as voltage signal 0-10V and connected to the terminals 13, 16 .
 - 4 PV is supplied as voltage signal 2-10V and connected to the terminals 13, 16
- * Not if a transmitter is connected in two-wire technology
(see also 5.: Electrical connection)




3.18 Input for remote setpoint SP (input SP) (at 6490 /1 /2 /5 and 6590 /1 /2 /5)

Selections:

- 0 SP is detected with a Pt100 sensor and connected to the terminals 14, 15, 16
- 1 SP is supplied as current signal 0-20 mA and connected to the terminals 12, 16.
- 2 SP is supplied as current signal 4-20mA and connected to the terminals 12, 16.
- 3 SP is supplied as voltage signal 0-10V and connected to the terminals 13, 16 .
- 4 SP is supplied as voltage signal 2-10V and connected to the terminals 13, 16

By detected signal failure: changeover to internal setpoint.
(see also 5.: Electrical connection)

3.19 Measured value filter for process variable PV



Software low-pass filter 1st order with adjustable time constant Tf to suppress interference signals and to smooth small process variable fluctuations.


Setting range: 100 to 255

Following assignments apply:

Input:	255	254	252	250	240	230*	220	200
Tf [s]:	10,22	5,10	2,54	1,69	0,62	0,37	0,26	0,16

*standard setting

Formula:
Tf = -0,04/ln(input/256)



3.20 Response to sensor failure PV (sensor break)

Response of actuator in case of: sensor short-circuit, sensor break, too low or too high signal value at 4-20 mA and 2-10 V signals.

Selections: 0 Actuator closes


- 1 Actuator opens
- 2 Actuator stops in its current position

The error message **Err** is indicated in the LED - display PV in the case of a transmitter / sensor fault. Alarmmessage, when alarm A, B or C is configured, independent of adjusted limit value.



Once the fault has been rectified, the controller reverts automatically to normal mode.

Monitoring is not possible in the case of electrical input signal without live zero point, 0-20 mA or 0-10 V.




3.21 Interlocking manual -/ automatic changeover (manual)

Selections: 0 Changeover via keyboard possible at any time

1 Interlocking in current status


Changeover MAN. to -1- in automatic mode : always automatic mode

Changeover MAN. to -1- in manual mode : always manual mode




3.22 Direction of action of controller

- Selections: 0 Heating controller: Actuator closes at increasing process variable PV
 1 Cooling controller: Actuator opens at increasing process variable PV



3.23 Function of the digital inputs (Open, Close, Stop) (at 6490 / 3 / 4 and 6590 / 3 / 4)


- Selections: 0 No control function
 Switch status of the digital inputs is transmitted via the MODBUS
 1 Control function Open, Close, Stop
 Switch status of the digital inputs is additionally transmitted via the MODBUS



3.24 Transmitting speed for serial interface (baud) (at 6490 / 3 / 4 and 6590 / 3 / 4)

Serial interface RS 485, data transmission in conformity with MODBUS protocol in RTU - mode.


- Selections: 0 19200 baud 3 2400 baud
 1 9600 baud 4 1200 baud
 2 4800 baud



3.25 Address for serial interface (at 6490 / 3 / 4 and 6590 / 3 / 4)

Setting range: 1 to 247

Address of the controller.



3.26 Serial communication (at 6490 / 3 / 4 and 6590 / 3 / 4)

- Selections: 0 Operation from the controller and master is possible.
 1 The controller can only be operated from the master (except configuration point S.C).
 Local blocking of operation.

MODBUS initialization (at 6490 / 3 / 4 and 6590 / 3 / 4)

After the interface has been configured briefly disconnect the device from power supply.

This applies to a change in settings of:

- 3.24 Transmitting speed for serial interface
- 3.25 Address for serial interface
- 3.26 Serial communication

OL2



P

3.27 Second operating level (operating level 2)

Selecting the functions for the user - defined operating level.

Setting range: 0 to 31: (at 6490 /0 /1 /2 /5 and 6590 /0 /1 /2 /5)

- 0 No second operating level
- 1 Self - optimization can be activated at the 2nd operating level (see also 3.1: OPT)
- 2 Limit and hysteresis of the selected alarm can be entered at the 2nd operating level (see also 3.7 respectively 3.8: Alarms)
- 4 Remote / local changeover on the 2nd operating level is possible (see also 3.12: rE.L)
- 8 The second setpoint SP.2 is adjustable on the 2nd operating level (see also 3.13: SP.2)
- 16 The setpoint ramp SP.r can be set, switchend on and off on the operating level 2 (see also 3.14: SP.r)

Setting range: 0 to 31: (at 6490 /3 /4 and 6590 /3 /4)

- 0 No second operating level
- 1 Self - optimization can be activated at the 2nd operating level (see also 3.1: OPT)
- 2 Limit and hysteresis of the selected alarm can be entered at the 2nd operating level (see also 3.7 respectively 3.8: Alarms)
- 4 Serial communication can be defined on 2nd operating level (see also 3.26: S.C)
- 16 The setpoint ramp SP.r can be set, switchend on and off on the operating level 2 (see also 3.14: SP.r)

The distinctive numbers of the required functions are added, and the result is entered.
The password must have been activated. (see also 3.28: PAS)

PAS

0



P

3.28 Access to the parameterization / configuration level (password)

Interlocking the parameterization / configuration level via the password **Cod** prevents unauthorized access.


- Selections: 0 No interlocking of the parameterization / configuration level. OL.2 ineffective.
- 1 Access to the parameterization / configuration level only after keyboard entry of the password. OL.2 effective.
(see also 3.27 OL.2; valid password: see page 26:

PAS / Cod)


4. Mounting

The device is suitable for front panel installation and for integration in any position into consoles. Insert the controller from the front into the prepared panel cut - off and secure with the supplied clamping tool.

-  The ambient temperature at the point of installation must not exceed the permissible temperature for rated operation. Adequate ventilation must be assured, even with a high device packing density.
- The device must not be installed within explosion - hazardous areas.



Device dimensions 6490



Device dimensions 6590

5. Electrical connection

The plug - type terminals and wiring diagram are located at the back of the device.

The given national rules must be observed for installation (in Germany DIN VDE 0100).



-  The electrical connection must be completed in conformity with the connection diagrams of the device. Screened cables must be used for the measurement and control leads (digital inputs). These leads must be conducted separately from the power current cables in the switch cabinet. It is essential to check before the device is switched on that the operating voltage specified on the rating plate conforms with the mains voltage.
- The connecting terminals must only be disconnected from the device while the connected lines are in a de - energized state.

Maximum configuration (6490 / 4 and 6590 / 4)

Minimum configuration (6490 / 0 and 6590 / 0)


(see also 8. Order number)

(see also 8. Order number)



With 6490: Valid from device number 5000 onwards. See rating plate.

5.1 Wiring diagram



6. Commissioning

Procedure:	Corrective measures in case of malfunctions
<input type="checkbox"/> Unit properly installed ?	see also 4.: Installation
<input type="checkbox"/> Electrical connection according to valid regulations and connection diagrams ?	see also 5.: Electrical connection
<input type="checkbox"/> Switch on mains voltage. When the unit is switched on, all display elements in the front plate will light up for approx. 2 sec. (lamp test). The unit is then ready for operation.	Compare operating voltage, indicated on the type plate, to mains voltage.
<input type="checkbox"/> Switch over to manual mode.	see also 2.2: Manual mode
<ul style="list-style-type: none"> • Does the actual value display PV correspond to process variable at measuring point ? 	Check sensor, measuring line and electrical connection. see also 5.: Electrical connection
<ul style="list-style-type: none"> • Actual value display PV fluctuating / jumping ? 	Adjust measuring filter FIL. see also: 3.19: FIL Unit in the immediate vicinity of powerful electrical or magnetic interference fields ?
<ul style="list-style-type: none"> • Connect digital inputs* 	see also 5.: Electrical connection
<ul style="list-style-type: none"> - Are the corresponding LEDs on the front plate illuminated ? 	Check voltage supply for digital inputs, remote switching contacts, signal lines and electrical connection. see also 5.1: Wiring diagram
<ul style="list-style-type: none"> • Supply remote setpoint and switch over to remote operation* 	see also 3.18: In.S ; 3.12: re.L ; 3.26: S.C
<ul style="list-style-type: none"> - Is remote setpoint SP displayed correctly ? 	Check setpoint transmitter, measuring line and electrical connection. see also 5.1: Wiring diagram
<ul style="list-style-type: none"> • Open actuator <ul style="list-style-type: none"> - Heating controller: Actual value PV increasing ? - Cooling controller: Actual value PV degreasing ? • Close actuator <ul style="list-style-type: none"> - Heating controller: Actual value PV decreasing ? - Cooling controller: Actual value PV increasing ? 	see also 2.2: Manual operation No response: Check actuator and electrical connection controller - actuator reverse response: Interchange actuator drive OPEN and CLOSE see also 5.1: Wiring diagram
<ul style="list-style-type: none"> • Enter actuating time of connected actuator. 	see also 3.6: t.P
<ul style="list-style-type: none"> • Set control parameters using self - optimization. 	see also 3.1: OPt
<input type="checkbox"/> Automatic mode	
Manual -/ automatic changeover	see also 2.2: Manual mode
Set setpoint SP	see also 2.1: Setting the setpoint SP in the automatic mode
<input type="checkbox"/> Controller actuating pulses too short, switching rate too high	Adjust dead band db see also 3.5: db


* Option

7. Technical data

Power supply	230 V AC 115 V AC 24 V AC	} -15 % / +10 %, 50 / 60 Hz
Power consumption	approx. 7 VA	
Weight	approx. 1 kg	
Permissible ambient temperature		
- Operation	0 to 50°C	
- Transport and storage	-25° to + 65°C	
Degree of protection	Front IP 65 according to DIN 40050	
Design	For control panel installation 96 x 96 x 135 mm at 6490 and 48 x 96 x 140 at 6590 (W x H x D)	
Installation position	arbitrary	
DI - feed voltage and measuring transducer feed voltage	24 V DC, I _{max.} = 60 mA	
Analog inputs	Pt100, 2.4 = 0°C to 300°C or 2.2 = 0°C to 400°C Connection in three - wire system 0/4 to 20 mA, input resistance = 50 Ohm 0/2 to 10 V, input resistance = 100 KOhm	
Accuracy	0.1% of measuring range	
Digital inputs	high active, R _i = 1 k K ; n.c. / 0V DC = low 12 V to 24 V DC = high	
Analog output for process variable	0 to +10 V comply with 0° to 300°C (2.4) or 0° to 400°C (2.2), I _{max.} = 2 mA	
Displays	Two 4 - digit 7- segment displays, LED ,red, digit height = 13 mm (6490), 10 mm (6590)	
Alarm	Alarm type A, B, C; normally closed contact principle	
Relays	Contact equipment: 1 change - over contact Switching capacity: 250 V AC / 3 A Spark quenching element	
Serial interface	RS 485, MODBUS - protocol in RTU - mode 1200 to 19200 Baud 1 start bit, 8 data bits, 1 stop bit, no parity	
Data storage	Semi - conductor memory	

8. Ordering number baelz 6490 / baelz 6590

Examples : 6490 / 0 - 2.4 - 230 - 00.0
 6590 / 3 - 2.2 - 115 - S7.1



Type / version 6490.. and 6590..	../0	../1	../2	../3	../4	../5
Equipment:						
PI(D) - three - position step -output	✓	✓	✓	✓	✓	✓
Alarm relay 1	✓	✓	✓	✓	✓	✓
1 measuring input Pt100	✓	✓	✓	✓	✓	✓
1 measuring input 0 / 4 ... 20 mA		✓	✓	✓	✓	✓
1 measuring input 0 / 2 ... 10V		✓	✓	✓	✓	✓
Measuring transducer feed voltage 24 V DC		✓	✓	✓	✓	✓
1 digital input (external setpoint)		✓				✓
4 digital inputs (open, close, stop, setpoint 2)				✓	✓	
5 digital inputs (open, close, stop, ext. setpoint, setpoint 2)			✓			
1 Pt100 - process variable output 0...+10V			✓		✓	✓
1 Interface RS485 (MODBUS RTU)				✓	✓	
Alarm relay 2				✓	✓	✓

Operating Instructions

OI 6490 / 6590

9. Overview of parameterization -/ configuration level, data list

<u>Parameter / configuration point</u>	<u>Display</u>	<u>Settings</u>	<u>Remarks</u>
Optimization	OPt	0 1	No self - optimization Activate if required
Proportional band	Pb	<input type="text"/>	1,0 to 999,9 %
Three - position controller	Pb =	0 <input type="checkbox"/>	tn > 0; db comply with dead zone
Integral action time	tn	<input type="text"/>	1 to 2600 s
Two - position controller	tn =	0 <input type="checkbox"/>	db comply with dead zone
Derivative action time	td	<input type="text"/>	1 to 255s; PI - control at td = 0
Dead band (dead zone)	db	<input type="text"/>	0 to measuring range [phys. unit] (x 0,1 at dP = 0)
Valve actuating time	tP	<input type="text"/>	5 to 300 s
Alarm at 6490 /0 /1 /2 and at 6590 /0 /1 /2	AL	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/>	No alarm, also not in case of sensor failure Alarm A, dependent on setpoint Alarm B, fixed limit value Alarm C, band transgression by setpoint and in case of sensor failure independent of adjusted limit value
Alarm A	AL.=	<input type="text"/>	0 to ± extent of measuring range [phys. unit] at AL = 1
Reset hysteresis	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm B	AL.-	<input type="text"/>	Measuring range: dI.L to dI.H [phys. unit] at AL = 2
Reset hysteresis	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm C, lower limit	AL.=	<input type="text"/>	0 to - extent of measuring range [phys. unit] at AL = 3
Reset hysteresis, lower limit	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm C, upper limit	AL.=	<input type="text"/>	0 to + extent of measuring range [phys. unit] at AL = 3
Reset hysteresis, upper limit	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm at 6490 /3 /4 /5 and at 6590 /3 /4 /5	AL	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/>	No alarm, also not in case of sensor failure Alarm relay 1 = A, no alarm relay 2 Alarm relay 1 = B, no alarm relay 2 Alarm relay 1 = A, alarm relay 2 = A Alarm relay 1 = B, alarm relay 2 = A Alarm relay 1 = C (A1 v A2), alarm relay 2 = A Alarm relay 1 = B v A2, alarm relay 2 = A Alarm relay 1 in case of sensorfailure independent of adjusted limit value
Alarm 1 = A	AL.=	<input type="text"/>	0 to ± extent of measuring range [phys. unit] at AL = 1, 3, 5
Reset hysteresis	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm 1 = B	AL.-	<input type="text"/>	Measuring range: dI.L to dI.H [phys. unit] at AL = 2, 4, 6
Reset hysteresis	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Alarm 2 = A	AL.=	<input type="text"/>	0 to ± extent of measuring range [phys. unit] at AL = 3, 4, 5, 6
Reset hysteresis	HYS	<input type="text"/>	0 to extent of measuring range [phys. unit] (x0,1 at dP = 0)
Decimal point	dP	0 <input type="checkbox"/> 1 <input type="checkbox"/>	Display without decimal point Display with decimal point
Scaling, low	dI.L	<input type="text"/>	Displayed value at start of measuring range, -999 to dI.H-1 [phys. unit]
Scaling, high	dI.H	<input type="text"/>	Displayed value at end of measuring range dI.L+1 to 9999 [phys. unit]
Setpoint limit, lower	SP.L	<input type="text"/>	dI.L to SP.H [phys. unit] not valid for SP.2
Setpoint limit, upper	SP.H	<input type="text"/>	SP.L to dI.H [phys. unit] and remote setpoints
Remote -/ local changeover*	rE.L	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/>	Only local setpoint Changeover via digital input REM / LOC, setpoint via analog input Jolt - free (smooth) remote -/ local changeover, by tracking SP loc. = SP rem., otherwise as 1

Operating Instructions

OI 6490 / 6590

<u>Parameter / configuration point</u>	<u>Display</u>	<u>Settings</u>	<u>Remarks</u>	
Second setpoint *	SP.2	<input type="text"/>	dI.L to dI.H [phys. unit] Changeover via digital input SP.2	
Setpoint ramp	SP.r	<input type="text"/>	0 to measuring range [phys. unit per min]	
Ramp direction	rA.d	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/>	<input type="checkbox"/> Increasing and decreasing setpoint ramp <input type="checkbox"/> Only increasing setpoint ramp <input type="checkbox"/> Only decreasing setpoint ramp	
Process gain	P.G	<input type="text"/>	1 to 255 %, for self - optimization	
Process variable input PV	In.P	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/>	Pt 100 2.4 = 0° to 300°C or 2.2 = 0° to 400°C 0 to 20 mA 4 to 20 mA 0 to 10 V 2 to 10 V	
Remote setpoint input *	In.S	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/>	Pt 100 2.4 = 0° to 300°C or 2.2 = 0° to 400°C 0 to 20 mA 4 to 20 mA 0 to 10 V 2 to 10 V	by detected signal failure: changeover to internal setpoint
Measured value filter PV	FIL	<input type="text"/>	100 to 255 comply with 42 ms to 10 s	
Sensor break PV	SE.b	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/>	<input type="checkbox"/> Actuator closes <input type="checkbox"/> Actuator opens <input type="checkbox"/> Actuator stops in its current position	
Manual -/ automatic changeover	MAN	0 <input type="checkbox"/> 1 <input type="checkbox"/>	<input type="checkbox"/> Changeover via keyboard <input type="checkbox"/> Interlocking in current status automatic <input type="checkbox"/> Interlocking in current status manual	
Direction of action of controller	dIr	0 <input type="checkbox"/> 1 <input type="checkbox"/>	<input type="checkbox"/> Heating controller <input type="checkbox"/> Cooling controller	
Function of the digital inputs	OCS	0 <input type="checkbox"/> 1 <input type="checkbox"/>	<input type="checkbox"/> No control function <input type="checkbox"/> Control function Open, Close, Stop	Switch status of the digital inputs is transmitted via the MODBUS.
Transfer rate *	bd	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/>	<input type="checkbox"/> 19200 baud <input type="checkbox"/> 9600 baud <input type="checkbox"/> 4800 baud <input type="checkbox"/> 2400 baud <input type="checkbox"/> 1200 baud	
Adress *	Adr	1 bis 247 <input type="text"/>	Slave address at bus - mode Adress	
Serial communication *	S.C	0 <input type="checkbox"/> 1 <input type="checkbox"/>	<input type="checkbox"/> The master only can read data from the controller <input type="checkbox"/> The controller is operated and set using the master	
Second operating level	OL.2	0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 4 <input type="checkbox"/> 8 <input type="checkbox"/> 16 <input type="checkbox"/> <input type="text"/>	<input type="checkbox"/> No second operating level <input type="checkbox"/> Self - optimization <input type="checkbox"/> Limit value and hysteresis of alarm <input type="checkbox"/> Remote -/ local changeover * or serial communication ¹⁾ <input type="checkbox"/> Second setpoint * <input type="checkbox"/> Setpoint ramp Result of added indentifier numbers	Add figures of desired functions and set PAS to 1 ¹⁾ Device with serial interface
Password	PAS	0 <input type="checkbox"/> 1 <input type="checkbox"/>	<input type="checkbox"/> No interlocking, OL.2 deactive <input type="checkbox"/> Access only after entry of the password, OL.2 active, Functions on OL.2 not interlocked	
* Option		<input type="text"/> 1500	Code	